4 Port Desktop N-Wireless Router (P/N DA2154)

User's Guide

1308210 REV. A

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343

©Copyright 2012 by Legrand, Inc All Rights Reserved.

www.onqlegrand.com

Compliance

FCC Notice – FCC ID:YV8-DA2154V1
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Canadian Department of Communications – IC:9922A-DA2154V1
This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

This Class B digital apparatus complies with Canadian ICES-003.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

TABLE OF CONTENTS

1.0 Introduction 1
1.1 Overview of the Router 1
1.2 Main Features 1
1.3 Panel Layout 2
1.3.1 The Front Panel 2
1.3.2 The Rear Panel 3
2.0 Connecting the Router 4
2.1 System Requirements 4
2.2 Installation Environment Requirements 4
2.3 Connecting the Router 4
3.0 Quick Installation Guide 6
3.1 TCP/IP Configuration 6
3.2 Quick Installation Guide 7
4.0 Configuring the Router 13
4.1 Login 13
4.2 Status 14
4.3 Quick Setup 14
4.4 WPS 14
4.5 Network 17
4.5.1 WAN 18
4.5.2 MAC Clone 28
4.5.3 LAN 28
4.6 Wireless 29
4.6.1 Wireless Settings 30
4.6.2 Wireless Security 33
4.6.3 Wireless MAC Filtering 35
4.6.4 Wireless Advanced 37
4.6.5 Wireless Statistics 38
4.7 DHCP 39
4.7.1 DHCP Settings 39
4.7.2 DHCP Client List 40
4.7.3 Address Reservation 41
4.8 Forwarding 42
4.8.1 Virtual Servers 42
4.8.2 Port Triggering 44
4.8.3 DMZ 46
4.8.4 UPnP 46
4.9 Security 47
4.9.1 Basic Security 47
4.9.2 Advanced Security 49
4.9.3 Local Management 50
4.9.4 Remote Management 51
4.10 Parental Control 52
4.11 Access Control 54

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343

©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.11.1 Rule 55
4.11.2 Host 60
4.11.3 Target 61
4.11.4 Schedule 63
4.12 Advanced Routing 65
4.12.1 Static Routing 65
4.12.2 System Routing Table 66
4.13 Bandwidth Control 67
4.13.1 Control Settings 67
4.13.2 Rules List 67
4.14 IP & MAC Binding 69
4.14.1 Binding Settings 69
4.14.2 ARP List 70
4.15 Dynamic DNS 71
4.15.1 Comexe.cn DDNS 72
4.15.2 Dyndns.org DDNS 73
4.15.3 No-ip.com DDNS 74
4.16 System Tools 75
4.16.1 Time Settings 75
4.16.2 Diagnostic 77
4.16.3 Firmware Upgrade 78
4.16.4 Factory Defaults 79
4.16.5 Backup & Restore 80
4.16.6 Reboot 80
4.16.7 Password 81
4.16.8 System Log 81
4.16.9 Statistics 83
Appendix A: FAQ 85
Appendix B: Configuring the PC 91
Appendix C: Specifications 94
Appendix D: Glossary 95

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343

©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

1.0 Introduction

1.1 Overview of the Router

The Legrand DA2154-V1 Desktop 300Mbps Wireless N Router integrates a 4-port Switch, Firewall, NAT-Router and Wireless Access Point to fully meet the need of Small Office/Home Office (SOHO) network users demanding higher networking performance. It provides a wireless connection up to 300Mbps with other 802.11n wireless clients, while still being compatible with all IEEE 802.11g and IEEE 802.11b products. The DA2154-V1 provides security features such as SSID broadcast control, wireless LAN 64/128/152-bit WEP encryption, WiFi protected Access (WPA2- PSK, WPA- PSK), as well as advanced Firewall protection for complete data privacy. It also supports flexible access control, Virtual Server and DMZ host for Port Triggering, and allows for remote management.

1.2 Main Features

- Complies with IEEE 802.11n to provide a wireless data rate of up to 300Mbps.
- One 10/100M Auto-Negotiation RJ45 WAN port and four 10/100M Auto-Negotiation RJ45 LAN ports, supporting Auto MDI/MDIX.
- Provides WPA/WPA2, WPA-PSK/WPA2-PSK authentication and TKIP/AES encryption security.
- Supports Dynamic IP/Static IP/PPPoE Internet access.
- Supports Virtual Server and DMZ host.
- Supports UPnP, Dynamic DNS and Static Routing.
- Provides Automatic-connection and Scheduled (time-based) Connection to the Internet
- Built-in NAT and DHCP server supporting static IP address distributing.
- Supports Parental Control and Access Control.
- Connects Internet on demand and disconnects from the Internet when idle for PPPoE.
- Provides 64/128/152-bit WEP encryption security and wireless LAN ACL (Access Control List).
- Supports Flow Statistics.
- Supports firmware upgrades and web management.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

1.3 Panel Layout

1.3.1 The Front Panel



Figure 1-1 Front Panel sketch

The Router's LEDs are located on the front panel (View from left to right).

Name	Status	Indication
PWR	Off	Power is off.
	On	Power is on.
SYS	Flashing	The Router is working properly.
	On /Off	The Router has a system error.
WLAN	Off	The Wireless function is disabled.
	Flashing	The Wireless function is enabled.
WAN /LAN 1-4	Off	There is no device linked to the corresponding port.
	On	There is a device linked to the corresponding port but there is no activity.
	Flashing	There is an active device linked to the corresponding port.
WPS	Slow Flash	A wireless device is connecting to the network by WPS function. This process will last in the first 2 minutes.
	On	A wireless device has been successfully added to the network by WPS function.
	Quick Flash	A wireless device failed to be added to the network by WPS function.

Table 1-1 The LEDs Description

☞ **Note:**

1. **After a device is successfully added to the network by WPS function, the WPS LED will stay on for about 5 minutes and then turn off.**

2. **Press and hold the WPS/Reset button for more than 5 seconds, to reset the router.**

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

1.3.2 The Rear Panel



Figure 1-2 Rear Panel sketch

The following parts are located on the rear panel (View from left to right).

- **POWER:** The Power socket is where you will connect the power adapter. Please use the power adapter provided with this product.
- **ON/OFF:** The switch for the power.
- **4,3,2,1 (LAN):** These ports (4,3,2,1) connect the Router to the local devices (ie.PCs).
- **WAN:** This WAN port is where you will connect the DSL/Cable Modem, or Ethernet.
- **Wireless antenna:** To receive and transmit the wireless data.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

2.0 Connecting the Router

2.1 System Requirements

- Broadband Internet Access Service (DSL/Cable/Ethernet)
- One DSL/Cable Modem that has an RJ45 connector (which is not necessary if the Router is connected directly to the Ethernet.)
- PCs with a working Ethernet Adapter and an Ethernet cable with RJ45 connectors
- TCP/IP protocol on each PC
- Web browser, such as Microsoft Internet Explorer, Mozilla Firefox or Apple Safari

2.2 Installation Environment Requirements

- Place the Router in a well ventilated place far from any heater or heating vent
- Avoid direct sunlight
- Keep at least 2 inches (5 cm) of clear space around the Router
- Operating Temperature: 0°C~40°C (32°F~104°F)
- Operating Humidity: 10%~90%RH, Non-condensing

2.3 Connecting the Router

Before installing the Router, make sure your PC is able to be connected to the Internet through the broadband service successfully. If there is any problem, please contact your ISP. After that, please install the Router according to the following steps. Don't forget to pull out the power plug and keep your hands dry.

1. Power off your PC, Cable/DSL Modem, and the Router.
2. Locate an optimum location for the Router. The best place is usually at the center of your wireless network.
3. Adjust the direction of the antenna. Normally, upright is a good direction.
4. Connect the PC(s) and each Switch/Hub in your LAN to the LAN Ports on the Router, shown in Figure 2-1. (If you have the wireless NIC and want to use the wireless function, you can skip this step.)
5. Connect the DSL/Cable Modem to the WAN port on the Router, shown in Figure 2-1.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

6. Connect the power adapter to the power socket on the Router, and the other end into an electrical outlet. The Router will start to work automatically.

7. Power on your PC and Cable/DSL Modem.



Figure 2-1 Hardware Installation of the DA2154-V1 Desktop Router

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

3.0 Quick Installation Guide

This chapter will show you how to configure the basic functions of your DA2154-V1 Desktop Router using the **Quick Setup Wizard** within minutes.

3.1 TCP/IP Configuration

The default IP address of the DA2154-V1 is 192.168.40.254, and the default Subnet Mask is 255.255.255.0. These values can be changed as you desire.

Connect a local PC to a LAN port of the Router. And then you can configure the IP address for your PC in the following two ways.

- Configure the IP address manually

  1) Set up the TCP/IP Protocol for your PC. If you need instructions as to how to do this, please refer to Appendix B: "Configuring the PC".

  2) Configure the network parameters. The IP address is 192.168.40.xxx ("xxx" is any number from 1 to 250), Subnet Mask is 255.255.255.0, and Gateway is 192.168.40.254 (The Router's default IP address)

- Obtain an IP address automatically

  1) Set up the TCP/IP Protocol in "**Obtain an IP address automatically**" mode on your PC. If you need instructions as to how to do this, please refer to Appendix B: "Configuring the PC".

  2) Then the built-in DHCP server will assign IP address for the PC.

Now, you can run the Ping command in the **command prompt** to verify the network connection between your PC and the Router. The following example is in Windows 2000 OS.

Open a command prompt, and type *ping 192.168.40.254*, and then press **Enter**.

- If the result displayed is similar to the Figure 3-1, it means the connection between your PC and the Router has been established well.

```
Pinging 192.168.40.254 with 32 bytes of data:

Reply from 192.168.40.254: bytes=32 time<1ms TTL=64
Reply from 192.168.40.254: bytes=32 time<1ms TTL=64
Reply from 192.168.40.254: bytes=32 time<1ms TTL=64
Reply from 192.168.40.254: bytes=32 time<1ms TTL=64

Ping statistics for 192.168.40.254:
      Packets: Sent = 4, Received = 4, Lost = 0 (0% loss),
Approximate round trip times in milli-seconds:
      Minimum = 0ms, Maximum = 0ms, Average = 0ms
```

Figure 3-1 Success result of Ping command

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

➢ If the result displayed is similar to the Figure 3-2, it means the connection between your PC and the Router has failed.

```
Pinging 192.168.40.254 with 32 bytes of data:

Destination host unreachable.
Destination host unreachable.
Destination host unreachable.
Destination host unreachable.

Ping statistics for 192.168.40.254:
      Packets: Sent = 4, Received = 0, Lost = 4 (100% loss),
```

Figure 3-2 Failure result of Ping command

Please check the connection following these steps:

1. Is the connection between your PC and the Router correct?

☞ **Note: The 1/2/3/4 LEDs of LAN ports which you link to on the Router and LEDs on your PC's adapter should be lit.**

2. Is the TCP/IP configuration for your PC correct?

☞ **Note: If the Router's IP address is 192.168.40.254, your PC's IP address must be within the range of 192.168.40.1 ~ 192.168.40.250.**

3.2 Quick Installation Guide

With a web-based utility, it is easy to configure and manage the DA2154-V1 Router. The web-based utility can be used on any Windows, Macintosh or UNIX OS with a Web browser, such as Microsoft Internet Explorer, Mozilla Firefox or Apple Safari.

1. To access the configuration utility, open a web-browser and type in the default IP address 192.168.40.254 in the address field of the browser.

Figure 3-3 Log in the Router

After a moment, a login window will appear, similar to the Figure 3-4. Enter **admin** for the User Name and Password, both in lower case letters. Then click the **OK** button or press the **Enter** key.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Figure 3-4 Login Windows

☞ **Note: If the above screen does not pop-up, it means that your web-browser has been set to a proxy. Go to Tools menu>Internet Options>Connections>LAN Settings, in the screen that appears, cancel the Using Proxy checkbox, and click OK to finish it.**

1. After successfully logging in, you can click the **Quick Setup** menu to quickly configure your Router.


Quick Setup
Start >> WAN Connection Type >> Wireless >> Finish
The quick setup will tell you how to configure the basic network parameters.
To continue, please click the Next button.
To exit, please click the Exit button.
Exit
Next

Figure 3-5 Quick Setup

2. Click **Next**, and then **WAN Connection Type** page will appear, shown in Figure 3-6.


Quick Setup - WAN Connection Type
Start >> WAN Connection Type >> Wireless >> Finish
The Quick Setup is preparing to set up your connection type of WAN port.
The Router will try to detect the Internet connection type your ISP provides if you select the Auto-Detect option.
Otherwise, you need to specify the connection type manually.
Auto-Detect - Let the Router automatically detect the connection type your ISP provides.
PPPoE - Usually for ADSL Modem and you will need a PPPoE username and password from your ISP.
Dynamic IP - Usually for Cable Modem and the router will automatically obtain an IP address from the DHCP server.
Static IP - This type of connection uses a permanent, fixed (static) IP address that your ISP assigned.
Back
Next

Figure 3-6 WAN Connection Type

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

The Router provides **Auto-Detect** function and supports three popular ways (**PPPoE**, **Dynamic IP** and **Static IP)** to connect to the Internet. It's recommended that you make use of the **Auto-Detect** function. If you are sure of what kind of connection type your ISP provides, you can select that type and click **Next** to configure.

3. If you select **Auto-Detect**, the Router will automatically detect the connection type your ISP provides. Make sure the cable is securely plugged into the WAN port before detection. The appropriate configuration page will be displayed when an active Internet service is successfully detected by the Router.

   1) If the connection type detected is **PPPoE**, the next screen will appear as shown in Figure 3-7.



Figure 3-7 Quick Setup - PPPoE

- **User Name/Password -** Enter the **User Name** and **Password** provided by your ISP. These fields are case sensitive. If you have difficulty with this process, please contact your ISP.
- **Confirm Password -** Re-enter the password provided by your ISP to ensure the Password you entered is correct. If the Password is different from the Confirm Password, the screen will appear as shown below. Click **OK**, and re-enter the Password and Confirm Password.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

2) If the connection type detected is Dynamic IP, the screen shown in Figure 3-8 will appear.

- If you are visiting the Router from the main computer, please select **Yes**, and then click **Clone MAC Address**.


Quick Setup - MAC Clone
Start >> WAN Connection Type >> Wireless >> Finish
Please read help carefully on the right.
Yes, I am connected by the main computer (clone MAC address).
No, I am connected by another computer (do NOT clone MAC address).
WAN MAC Address:
00-0A-EB-13-09-1A
Restore Factory MAC
Your PC's MAC Address:
6c-62-6d-f7-32-09
Clone MAC Address
Back
Next

Figure 3-8 Quick Setup – MAC Clone

- If you are visiting the Router from another computer, rather than the main computer, please select **No**, and then enter the main computer's MAC in the field **WAN MAC Address**.


Quick Setup - MAC Clone
Start >> WAN Connection Type >> Wireless >> Finish
Please read help carefully on the right.
Yes, I am connected by the main computer (clone MAC address).
No, I am connected by another computer (do NOT clone MAC address).
WAN MAC Address:
00-0A-EB-13-09-1A
Restore Factory MAC
Your PC's MAC Address:
6c-62-6d-f7-32-09
Clone MAC Address
Back
Next

Figure 3-9 Quick Setup – MAC Clone

3) If the connection type detected is Static IP, the screen shown in Figure 3-10 will appear.



Figure 3-10 Quick Setup - Static IP

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **IP Address -** This is the WAN IP address as seen by external users on the Internet (including your ISP). Enter the IP address into the field.
- **Subnet Mask -** The Subnet Mask is used for the WAN IP address, it is usually 255.255.255.0.
- **Default Gateway -** Enter the gateway IP address into the box if required.
- **Primary DNS -** Enter the DNS Server IP address into the box if required.
- **Secondary DNS -** If your ISP provides another DNS server, enter it into this field.

4. Click **Next** to continue, the Wireless settings page will appear as shown in Figure 3-11.



Figure 3-11 Quick Setup – Wireless

- **Wireless Radio -** The wireless radio can only be enabled/disabled by using the WIFI ON/OFF switch on the device.
- **Wireless Network Name -** Enter a value of up to 32 characters. The same name of SSID (Service Set Identification) must be assigned to all wireless devices in your network. The default SSID is set to be Legrand_XXXXXX (XXXXXX indicates the last unique six numbers of the Router's MAC address). This value is case-sensitive. For example, *TEST* is NOT the same as *test*.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Region -** Select your region from the drop-down list. This field specifies the region where the wireless function of the Router can be used. It may be illegal to use the wireless function of the Router in a region other than one of those specified in this field. If your country or region is not listed, please contact your local government agency for assistance.

  ☞ **Note: Because of limits set by local law regulations, versions for North America may not have the region selection option.**

- **Mode -** This field determines the wireless mode which the Router works on.
- **Channel Width -** Select any channel width from the drop-down list. The default setting is automatic, which can adjust the channel width for your clients automatically.
- **Channel -** This field determines which operating frequency will be used. The default channel is set to **Auto**, so the AP will choose the best channel automatically. It is not necessary to change the wireless channel unless you notice interference problems with another nearby access point.
- **Max Tx Rate -** Maximum transmission rate of the Router may be limited with this field.
- **Disable Security -** The wireless security function can be enabled or disabled. If disabled, the wireless stations will be able to connect the Router without encryption. It is recommended strongly that you choose one of following options to enable security.
- **WPA-PSK/WPA2-PSK -** Select WPA based on pre-shared passphrase.
  - **PSK Password** - You can enter **ASCII** or **Hexadecimal** characters.

    For **ASCII**, the key can be made up of any numbers 0 to 9 and any letters A to Z, the length should be between 8 and 63 characters.

    For **Hexadecimal**, the key can be made up of any numbers 0 to 9 and letters A to F, the length should be between 8 and 64 characters.

    Please also note the key is case sensitive, this means that upper and lower case keys will affect the outcome. It would also be a good idea to write down the key and all related wireless security settings.
- **No Change -** If you chose this option, wireless security configuration will not change!

5. Click the **Next** button. You will then see the **Finish** page as shown in Figure 3-12.

   Click the **Finish** button to finish the **Quick Setup**.


Quick Setup - Finish
Congratulations! This device is now connecting you to the Internet. For detail settings, please click other menus if necessary.
Back
Finish

Figure 3-12 Quick Setup - Finish

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.0 Configuring the Router

4.1 Login

After your successful login, you will see the fifteen main menus on the left of the web-based utility. On the right, there are the corresponding explanations and instructions.



The detailed explanations for each web page's key function are listed below.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343

©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.2 Status

The Status page provides the current status information about the Router. All information is read-only.



Figure 4-1 Router Status

4.3 Quick Setup

Please refer to 3.2 Quick Installation Guide.

4.4 WPS

This section will guide you in the adding of a new wireless device to an existing network quickly by using the WPS **(Wi-Fi Protected Setup)** function.

a). Choose menu “WPS”, and you will see the screen shown in Figure 4-2.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Figure 4-2 WPS

- **WPS Status -** Enable or disable the WPS function here.
- **Current PIN -** The current value of the Router's PIN is displayed here. The default PIN of the Router can be found in the label attached on the router.
- **Restore PIN -** Restore the PIN of the Router to its default.
- **Gen New PIN -** Click this button, and then you can get a new random value for the Router's PIN. You can ensure the network security by generating a new PIN.
- **Disable PIN of this device -** You can disable the Router's PIN manually here. If the router receives multiple failed attempts to authenticate an external registrar, this function will be disabled automatically.
- **Add Device -** You can add a new device to the existing network manually by clicking this button.

b). To add a new device:

If the wireless adapter supports Wi-Fi Protected Setup (WPS), you can establish a wireless connection between wireless adapter and Router using either Push Button Configuration (PBC) method or PIN method.

☞ **Note: To build a successful connection by WPS, you should also do the corresponding configuration of the new device for WPS function at the same time.**

I. Use the Wi-Fi Protected Setup Button

Use this method if your client device has a Wi-Fi Protected Setup button.

Step 1: Press the WPS/RESET button on the back panel of the Router for one second.

You can also keep the default WPS Status as **Enabled** and click the **Add Device** button in Figure 4-2, then Choose "**Press the button of the new device in two minutes**" and click **Connect**. (Shown in the following figure)

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure 4-3 Add A New Device

Step 2: Press and hold the WPS button of the client device directly.

Step 3: The Wi-Fi Protected Setup LED flashes for two minutes during the Wi-Fi Protected Setup process.

Step 4: When the WPS LED is on, the client device has successfully connected to the Router.

Step 5: Refer back to your client device or its documentation for further instructions.

II. Enter the client device's PIN on the Router

Use this method if your client device has a Wi-Fi Protected Setup PIN number.

Step 1: Keep the default WPS Status as **Enabled** and click the **Add Device** button in Figure 4-2, then the following screen will appear.



Figure 4-4 Add A New Device

Step 2: Enter the PIN number from the client device in the field on the above WPS screen. Then click **Connect** button.

Step 3: "**Connect successfully**" will appear on the screen of Figure 4-4, which means the client device has successfully connected to the Router.

III. Enter the Router's PIN on your client device

Use this method if your client device asks for the Router's PIN number.

Step 1: On the client device, enter the PIN number listed on the Router's Wi-Fi Protected Setup screen. (It is also labeled on the bottom of the Router.)

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Step 2: The Wi-Fi Protected Setup LED flashes for two minutes during the Wi-Fi Protected Setup process.

Step 3: When the WPS LED is on, the client device has successfully connected to the Router.

Step 4: Refer back to your client device or its documentation for further instructions.

☞ **Note:**

1) **The WPS LED on the Router will light green for five minutes if the device has been successfully added to the network.**

2) **The WPS function cannot be configured if the Wireless Function of the Router is disabled. Please make sure the Wireless Function is enabled before configuring the WPS.**

4.5 Network



Figure 4-5 the Network menu

There are three submenus under the Network menu (shown in Figure 4-5): **WAN, MAC Clone** and **LAN.** Click any of them, and you will be able to configure the corresponding function.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.5.1 WAN

Choose menu "**Network → WAN**", to configure the IP parameters of the WAN on the screen below.

1. If your ISP provides DHCP service, please choose **Dynamic IP** type, and the Router will automatically get IP parameters from your ISP. You can see the page as follows (Figure 4-6):



Figure 4-6 WAN – Dynamic IP

This page displays the WAN IP parameters assigned dynamically by your ISP, including IP address, Subnet Mask, Default Gateway, etc. Click the **Renew** button to renew the IP parameters from your ISP. Click the **Release** button to release the IP parameters.

- **MTU Size -** The normal **MTU** (Maximum Transmission Unit) value for most Ethernet networks is 1500 Bytes. It is not recommended that you change the default **MTU Size** unless required by your ISP.

- **Use These DNS Servers -** If your ISP gives you one or two DNS addresses, select **Use These DNS Servers** and enter the primary and secondary addresses into the correct fields. Otherwise, the DNS servers will be assigned dynamically from your ISP.

☞ **Note: If you get an error message when you go to a website after entering the DNS addresses, it is likely that your DNS servers are set up improperly. You should contact your ISP to get the correct DNS server addresses.**

- **Host Name -** This option specifies the Host Name of the Router.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Get IP with Unicast DHCP -** A few ISPs' DHCP servers do not support broadcast applications. If you cannot get the IP Address normally, you can choose this option. (It is rarely required.)

Click the **Save** button to save your settings.

2. If your ISP provides a static or fixed IP Address, Subnet Mask, Gateway and DNS setting, select **Static IP**. The Static IP settings page will appear, shown in Figure 4-7.



Figure 4-7 WAN - Static IP

- **IP Address -** Enter the IP address in dotted-decimal notation provided by your ISP.
- **Subnet Mask -** Enter the subnet Mask in dotted-decimal notation provided by your ISP, usually is 255.255.255.0.
- **Default Gateway -** (Optional) Enter the gateway IP address in dotted-decimal notation provided by your ISP.
- **MTU Size -** The normal **MTU** (Maximum Transmission Unit) value for most Ethernet networks is 1500 Bytes. It is not recommended that you change the default **MTU Size** unless required by your ISP.
- **Primary/Secondary DNS -** (Optional) Enter one or two DNS addresses in dotted-decimal notation provided by your ISP.

Click the **Save** button to save your settings.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

3. If your ISP provides a PPPoE connection, select the **PPPoE** option. Then enter the following parameters (Figure 4-8):



Figure 4-8 WAN - PPPoE

- **User Name/Password -** Enter the User Name and Password provided by your ISP. These fields are case-sensitive.
- **Secondary Connection -** It's available only for PPPoE Connection. If your ISP provides an extra Connection type such as Dynamic/Static IP to connect to a local area network, then you can check the radio button of Dynamic/Static IP to activate this secondary connection.
  - **Disabled -** The Secondary Connection is disabled by default, so there is PPPoE connection only. This is recommended.
  - **Dynamic IP -** You can check this radio button to use Dynamic IP as the secondary connection to connect to the local area network provided by ISP.
  - **Static IP -** You can check this radio button to use Static IP as the secondary connection to connect to the local area network provided by ISP.
- **Connect on Demand -** In this mode, the Internet connection can be terminated automatically after a specified inactivity period (**Max Idle Time**) and be re-established when you attempt to access the Internet again. If you want your Internet connection keeps active all the time, please enter "0" in the **Max Idle Time** field. Otherwise, enter the number of minutes you want to have elapsed before your Internet access disconnects.
- **Connect Automatically -** The connection can be re-established automatically when it was down.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Time-based Connecting -** The connection will only be established in the period from the start time to the end time (both are in HH:MM format).

  ☞ **Note: Only when you have configured the system time on "System Tools Time" page, will the Time-based Connecting function take effect.**

- **Connect Manually -** You can click the **Connect/Disconnect** button to connect/disconnect immediately. This mode also supports the **Max Idle Time** function as **Connect on Demand** mode. The Internet connection can be disconnected automatically after a specified inactivity period and re-established when you attempt to access the Internet again.

  Click the **Connect** button to connect immediately. Click the **Disconnect** button to disconnect immediately.

Caution: Sometimes the connection cannot be terminated although you specify a time to Max Idle Time because some applications are visiting the Internet continually in the background.

If you want to do some advanced configurations, please click the **Advanced** button, and the page shown in Figure 4-9 will then appear:



Figure 4-9 PPPoE Advanced Settings

- **MTU Size -** The default MTU size is "1480" bytes, which is usually fine. It is not recommended that you change the default **MTU Size** unless required by your ISP.

- **Service Name/AC Name -** The service name and AC (Access Concentrator) name should not be configured unless you are sure it is necessary for your ISP. In most cases, leaving these fields blank will work.

- **ISP Specified IP Address -** If your ISP does not automatically assign IP addresses to the Router during login, please click "**Use IP address specified by ISP**" check box and enter the IP address provided by your ISP in dotted-decimal notation.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Detect Online Interval -** The Router will detect Access Concentrator online at every interval. The default value is “0”. You can input the value between “0” and “120”. The value “0” means no detect.
- **Primary DNS/Secondary DNS -** If your ISP does not automatically assign DNS addresses to the Router during login, please click “**Use the following DNS servers**” check box and enter the IP address in dotted-decimal notation of your ISP’s primary DNS server. If a secondary DNS server address is available, enter it as well.

Click the **Save** button to save your settings.

4. If your ISP provides BigPond Cable (or Heart Beat Signal) connection, please select **BigPond Cable**. And you should enter the following parameters (Figure 4-10):



Figure 4-10

- **User Name/Password -** Enter the User Name and Password provided by your ISP. These fields are case-sensitive.
- **Auth Server -** Enter the authenticating server IP address or host name.
- **Auth Domain -** Type in the domain suffix server name based on your location.

  e.g.

  NSW / ACT - **nsw.bigpond.net.au**
  VIC / TAS / WA / SA / NT - **vic.bigpond.net.au**
  QLD - **qld.bigpond.net.au**

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **MTU Size -** The normal **MTU** (Maximum Transmission Unit) value for most Ethernet networks is 1500 Bytes. It is not recommended that you change the default **MTU Size** unless required by your ISP.
- **Connect on Demand -** In this mode, the Internet connection can be terminated automatically after a specified inactivity period (**Max Idle Time**) and be re-established when you attempt to access the Internet again. If you want your Internet connection keeps active all the time, please enter "0" in the **Max Idle Time** field. Otherwise, enter the number of minutes you want to have elapsed before your Internet access disconnects.
- **Connect Automatically -** The connection can be re-established automatically when it was down.
- **Connect Manually -** You can click the **Connect**/**Disconnect** button to connect/disconnect immediately. This mode also supports the **Max Idle Time** function as **Connect on Demand** mode. The Internet connection can be disconnected automatically after a specified inactivity period and re-established when you attempt to access the Internet again.

  Click the **Connect** button to connect immediately. Click the **Disconnect** button to disconnect immediately.

Caution: Sometimes the connection cannot be terminated although you specify a time to Max Idle Time because some applications are visiting the Internet continually in the background.

Click the **Save** button to save your settings.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

5. If your ISP provides L2TP connection, please select **L2TP/Russia L2TP** option. And you should enter the following parameters (Figure 4-11):



Figure 4-11

- **User Name/Password -** Enter the User Name and Password provided by your ISP. These fields are case-sensitive.
- **Dynamic IP/ Static IP -** Choose either as given by your ISP. Click the **Connect** button to connect immediately. Click the **Disconnect** button to disconnect immediately.
- **Connect on Demand -** You can configure the Router to disconnect from your Internet connection after a specified period of inactivity (**Max Idle Time**). If your Internet connection has been terminated due to inactivity, **Connect on Demand** enables the Router to automatically re-establish your connection as soon as you attempt to access the Internet again. If you wish to activate **Connect on Demand**, check the radio button. If you want your Internet connection to remain active at all times, enter 0 in the **Max Idle Time** field. Otherwise, enter the number of minutes you want to have elapsed before your Internet connection terminates.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Connect Automatically -** Connect automatically after the Router is disconnected. To use this option, check the radio button.
- **Connect Manually -** You can configure the Router to make it connect or disconnect manually. After a specified period of inactivity (**Max Idle Time**), the Router will disconnect from your Internet connection, and you will not be able to re-establish your connection automatically as soon as you attempt to access the Internet again. To use this option, check the radio button. If you want your Internet connection to remain active at all times, enter "0" in the **Max Idle Time** field. Otherwise, enter the number of minutes that you wish to have the Internet connecting last unless a new link is requested.

Caution: Sometimes the connection cannot be disconnected although you specify a time to **Max Idle Time**, because some applications are visiting the Internet continually in the background.

Click the **Save** button to save your settings.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

6. If your ISP provides PPTP connection, please select **PPTP/Russia PPTP** option. And you should enter the following parameters (Figure 4-12):



Figure 4-12 PPTP Settings

- **User Name/Password -** Enter the User Name and Password provided by your ISP. These fields are case-sensitive.
- **Dynamic IP/ Static IP -** Choose either as you are given by your ISP and enter the ISP's IP address or the domain name.

  If you choose static IP and enter the domain name, you should also enter the DNS assigned by your ISP. And click the **Save** button.

  Click the **Connect** button to connect immediately. Click the **Disconnect** button to disconnect immediately.
- **Connect on Demand -** You can configure the Router to disconnect from your Internet connection after a specified period of inactivity (**Max Idle Time**). If your Internet connection has been terminated due to inactivity, **Connect on Demand** enables the Router to automatically re-

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

establish your connection as soon as you attempt to access the Internet again. If you wish to activate **Connect on Demand**, check the radio button. If you want your Internet connection to remain active at all times, enter “0” in the **Max Idle Time** field. Otherwise, enter the number of minutes you want to have elapsed before your Internet connection terminates.

- **Connect Automatically -** Connect automatically after the Router is disconnected. To use this option, check the radio button.
- **Connect Manually -** You can configure the Router to make it connect or disconnect manually. After a specified period of inactivity (**Max Idle Time**), the Router will disconnect from your Internet connection, and you will not be able to re-establish your connection automatically as soon as you attempt to access the Internet again. To use this option, click the radio button. If you want your Internet connection to remain active at all times, enter "0" in the **Max Idle Time** field. Otherwise, enter the number in minutes that you wish to have the Internet connecting last unless a new link is requested.

Caution: Sometimes the connection cannot be disconnected although you specify a time to **Max Idle Time** because some applications are visiting the Internet continually in the background.

Click the **Save** button to save your settings.

☞ **Note:**

If you don't know how to choose the appropriate connection type, click the Detect button to allow the Router to automatically search your Internet connection for servers and protocols. The connection type will be reported when an active Internet service is successfully detected by the Router. This report is for your reference only. To make sure the connection type your ISP provides, please refer to the ISP. The various types of Internet connections that the Router can detect are as follows:

- **PPPoE - Connections which use PPPoE that requires a user name and password.**
- **Dynamic IP - Connections which use dynamic IP address assignment.**
- **Static IP - Connections which use static IP address assignment.**

The Router cannot detect PPTP/L2TP/BigPond connections. If your ISP uses one of these protocols, then you must configure your connection manually.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.5.2 MAC Clone

Choose menu "**Network** → **MAC Clone**", to configure the MAC address of the WAN as shown on the screen below, Figure 4-13:



Figure 4-13 MAC Address Clone

Some ISPs require that you register the MAC Address of your adapter. Changes are rarely needed here.

- **WAN MAC Address -** This field displays the current MAC address of the WAN port. If your ISP requires you to register the MAC address, please enter the correct MAC address into this field in XX-XX-XX-XX-XX-XX format (X is any hexadecimal digit).
- **Your PC's MAC Address -** This field displays the MAC address of the PC that is managing the Router. If the MAC address is required, you can click the **Clone MAC Address To** button and this MAC address will fill in the **WAN MAC Address** field.

Click **Restore Factory MAC** to restore the MAC address of WAN port to the factory default value.

Click the **Save** button to save your settings.

☞ **Note: Only a PC on your LAN can use the MAC Address Clone function.**

4.5.3 LAN

Choose menu "**Network** → **LAN**", to configure the IP parameters of the LAN as shown below.



Figure 4-14 LAN

- **MAC Address -** The physical address of the Router, as seen from the LAN. The value can't be changed.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **IP Address -** Enter the IP address of your Router or reset it in dotted-decimal notation (factory default: 192.168.40.254).
- **Subnet Mask -** An address code that determines the size of the network. Normally use 255.255.255.0 as the subnet mask.

☞ **Note:**

1) **If you change the IP Address of LAN, you must use the new IP Address to log in the Router.**
2) **If the new LAN IP Address you set is not in the same subnet, the IP Address pool of the DHCP server will change accordingly at the same time，while the Virtual Server and DMZ Host will not take effect until they are re-configured.**

4.6 Wireless



Figure 4-15 Wireless menu

There are five submenus under the Wireless menu (shown in Figure 4-15): **Wireless Settings**, **Wireless Security, Wireless MAC Filtering, Wireless Advanced** and **Wireless Statistics.** Click any of them, and you will be able to configure the corresponding function.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.6.1 Wireless Settings

Choose menu "**Wireless → Wireless Settings**", to configure the basic settings for the wireless network as shown on this page.



Figure 4-16 Wireless Settings

- **Wireless Network Name -** Enter a value of up to 32 characters. The same name of SSID (Service Set Identification) must be assigned to all wireless devices in your network. Considering your wireless network security, the default SSID is Legrand_XXXXXX (XXXXXX indicates the last unique six numbers of each Router's MAC address). This value is case-sensitive. For example, *TEST* is NOT the same as *test*.

- **Region -** Select your region from the drop-down list. This field specifies the region where the wireless function of the Router can be used. It may be illegal to use the wireless function of the Router in a region other than one of those specified in this field. If your country or region is not listed, please contact your local government agency for assistance.

  When you select your local region from the drop-down list, click the **Save** button**,** then the Note Dialog appears. Click **OK**.

Microsoft Internet Explorer
Selecting the incorrect country may cause interference to other devices and violate the applicable law.
OK

Note Dialog

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

☞ **Note: Local law regulations may limit versions for North America to not have region selection option.**

- **Mode -** Select the desired mode. The default setting is 11bgn mixed.

  11b only - Select if all of your wireless clients are 802.11b.

  11g only - Select if all of your wireless clients are 802.11g.

  11n only- Select only if all of your wireless clients are 802.11n.

  11bg mixed - Select if you are using both 802.11b and 802.11g wireless clients.

  11bgn mixed - Select if you are using a mix of 802.11b, 11g, and 11n wireless clients.

  Select the desired wireless mode. When 11g only mode is selected, only 802.11g wireless stations can connect to the Router. When 11n only mode is selected, only 802.11n wireless stations can connect to the AP. It is strongly recommended that you set the Mode to **11bgn mixed**, and all of 802.11b, 802.11g, and 802.11n wireless stations can connect to the Router.

- **Channel width -** Select the channel width from the drop-down list. The default setting is automatic, which can adjust the channel width for your clients automatically.

  ☞ **Note: If 11b only, 11g only, or 11bg mixed is selected in the Mode field, the Channel Width selecting field will turn grey and the value will become 20M, which is unable to be changed.**

- **Channel -** This field determines which operating frequency will be used. The default channel is set to **Auto**, so the AP will choose the best channel automatically. It is not necessary to change the wireless channel unless you notice interference problems with another nearby access point.

- **Max Tx Rate -** You can limit the maximum tx rate of the Router through this field.

- **Enable Wireless Router Radio -** The wireless radio of this Router can be enabled or disabled to allow wireless stations to access. The wireless radio can only be enabled or disabled by using the WIFI ON/OFF switch on the device.

- **Enable SSID Broadcast -** When wireless clients survey the local area for wireless networks to associate with, they will detect the SSID broadcast by the Router. If you select the **Enable SSID Broadcast** checkbox, the Wireless Router will broadcast its name (SSID) on the air.

- **Enable WDS Bridging -** Check this box to enable WDS. With this function, the Router can bridge two or more Wireless LANs. If this checkbox is selected, you will have to set the following parameters as shown in Figure 4-17. Make sure the following settings are correct.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure 4-17

- **SSID(to be bridged)** - The SSID of the AP your Router is going to connect to as a client. You can also use the search function to select the SSID to join.
- **BSSID(to be bridged)** - The BSSID of the AP your Router is going to connect to as a client. You can also use the search function to select the BSSID to join.
- **Survey** - Click this button to search for all the active APs in the current channel.
- **Key type** - This option should be chosen according to the AP's security configuration. It is recommended that the security type is the same as your AP's security type
- **WEP Index** - This option should be chosen if the key type is WEP(ASCII) or WEP(HEX).It indicates the index of the WEP key.
- **Auth Type** - This option should be chosen if the key type is WEP(ASCII) or WEP(HEX).It indicates the authorization type of the Root AP.
- **Password** - If the AP your Router is going to connect to needs a password, you need to fill in the password in this blank.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.6.2 Wireless Security

Choose menu "**Wireless → Wireless Security**", to configure the security settings of your wireless network.

There are five wireless security modes supported by the Router: WEP (Wired Equivalent Privacy), WPA (Wi-Fi Protected Access), WPA2 (Wi-Fi Protected Access 2), WPA-PSK (Pre-Shared Key), WPA2-PSK (Pre-Shared Key).


Wireless Security
Disable Security
WPA/WPA2 - Personal(Recommended)
Version: WPA2-PSK
Encryption: AES
Wireless Password: 55428613
(You can enter ASCII characters between 8 and 63 or Hexadecimal characters between 8 and 64.)
Group Key Update Period: 0 Seconds (Keep it default if you are not sure, minimum is 30, 0 means no update)
WPA/WPA2 - Enterprise
Version: Automatic
Encryption: Automatic
Radius Server IP:
Radius Port: 1812 (1-65535, 0 stands for default port 1812)
Radius Password:
Group Key Update Period: 0 (in second, minimum is 30, 0 means no update)
WEP
Type: Automatic
WEP Key Format: Hexadecimal
Key Selected
WEP Key
Key Type
Key 1: Disabled
Key 2: Disabled
Key 3: Disabled
Key 4: Disabled
Save

Figure 4-18 Wireless Security

- **Disable Security -** If you do not want to use wireless security, check this radio button. But it's strongly recommended to choose one of the following modes to enable security.
- **WEP -** It is based on the IEEE 802.11 standard. If you check this radio button, you will find a notice in red as show in Figure 4-19.


WEP
Type: Automatic
WEP Key Format: Hexadecimal
Key Selected
WEP Key
Key Type
Key 1: Disabled
Key 2: Disabled
Key 3: Disabled
Key 4: Disabled
We do not recommend using the WEP encryption if this device operates in 802.11n mode due to the fact that WEP is not supported by 802.11n specification.

Figure 4-19

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Type -** you can choose the type for the WEP security on the drop-down list. The default setting is **Automatic**, which can select **Shared Key** or **Open System** authentication type automatically based on the wireless station's capability and request.
- **WEP Key Format - Hexadecimal** and **ASCII** formats are provided here. **Hexadecimal** format stands for any combination of hexadecimal digits (0-9, a-f, A-F) in the specified length. **ASCII** format stands for any combination of keyboard characters in the specified length.
- **WEP Key -** Select which of the four keys will be used and enter the matching WEP key that you create. Make sure these values are identical on all wireless stations in your network.
- **Key Type -** You can select the WEP key length (64-bit, or 128-bit, or 152-bit.) for encryption. "Disabled" means this WEP key entry is invalid.

  64-bit - You can enter 10 hexadecimal digits (any combination of 0-9, a-f, A-F, zero key is not promoted) or 5 ASCII characters.

  128-bit - You can enter 26 hexadecimal digits (any combination of 0-9, a-f, A-F, zero key is not promoted) or 13 ASCII characters.

  152-bit - You can enter 32 hexadecimal digits (any combination of 0-9, a-f, A-F, zero key is not promoted) or 16 ASCII characters.

  ☞ **Note: If you do not set the key, the wireless security function is still disabled even if you have selected Shared Key as Authentication Type.**

➢ **WPA /WPA2 – Enterprise -** It's based on Radius Server.

- **Version -** you can choose the version of the WPA security on the drop-down list. The default setting is **Automatic**, which can select **WPA (**Wi-Fi Protected Access) or **WPA2 (**WPA version 2) automatically based on the wireless station's capability and request.
- **Encryption -** You can select either **Automatic**, or **TKIP** or **AES.**



Figure 4-20

- **Radius Server IP -** Enter the IP address of the Radius server.
- **Radius Port -** Enter the port number of the Radius server.
- **Radius Password -** Enter the password for the Radius server.
- **Group Key Update Period -** Specify the group key update interval in seconds. The value should be 30 or above. Enter 0 to disable the update.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

➢ **WPA-PSK/WPA2-PSK – Personal (Recommended) -** It's the WPA/WPA2 authentication type based on pre-shared passphrase.

- **Version -** you can choose the version of the WPA-PSK security on the drop-down list. The default setting is **Automatic**, which can select **WPA-PSK** (Pre-shared key of WPA) or **WPA2-PSK** (Pre-shared key of WPA) automatically based on the wireless station's capability and request.
- **Encryption -** When **WPA-PSK** or **WPA** is set as the Authentication Type, you can select either **Automatic**, or **TKIP** or **AES** as Encryption.


WPA/WPA2 - Personal(Recommended)
Version:
Automatic(Recommended)
Encryption:
AES
PSK Password:
12345670
(You can enter ASCII characters between 8 and 63 or Hexadecimal characters between 8 and 64.)
Group Key Update Period:
0
Seconds (Keep it default if you are not sure, minimum is 30, 0 means no update)

Figure 4-21

- **PSK Passphrase -** You can enter ASCII characters between 8 and 63 characters or 8 to 64 Hexadecimal characters.
- **Group Key Update Period -** Specify the group key update interval in seconds. The value should be 30 or above. Enter 0 to disable the update.

Be sure to click the **Save** button to save your settings on this page.

4.6.3 Wireless MAC Filtering

Choose menu "**Wireless → MAC Filtering**", to control the wireless access by configuring the **Wireless MAC Filtering** function, as shown in Figure 4-22.



Figure 4-22 Wireless MAC Filtering

To filter wireless users by MAC Address, click **Enable**. The default setting is **Disabled**.

➢ **MAC Address -** The wireless station's MAC address that you want to filter.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Status -** The status of this entry, either **Enabled** or **Disabled**.
- **Description -** A simple description of the wireless station.

To Add a Wireless MAC Address filtering entry, click the **Add New…** button. The "**Add or Modify Wireless MAC Address Filtering entry**" page will appear, shown in Figure 4-23:



Figure 4-23 Add or Modify Wireless MAC Address Filtering entry

To add or modify a MAC Address Filtering entry, follow these instructions:

1. Enter the appropriate MAC Address into the **MAC Address** field. The format of the MAC Address is XX-XX-XX-XX-XX-XX (X is any hexadecimal digit). For example: 00-0A-EB-B0-00-0B.
2. Give a simple description for the wireless station in the **Description** field. For example: Wireless station A.
3. Select **Enabled** or **Disabled** for this entry on the **Status** drop-down list.
4. Click the **Save** button to save this entry.

To modify or delete an existing entry:

1. Click the word **Modify** in the entry you want to modify it, or the word **Delete** if you want to delete the entry.
2. Modify the information.
3. Click the **Save** button.

Click the **Enable All** button to make all entries enabled

Click the **Disable All** button to make all entries disabled.

Click the **Delete All** button to delete all entries.

Click the **Next** button to go to the next page.

Click the **Previous** button to return to the previous page.

For example: If you desire that the wireless station A with MAC address 00-0A-EB-B0-00-0B and the wireless station B with MAC address 00-0A-EB-00-07-5F are able to access the Router, but all the other wireless stations cannot access the Router, you can configure the **Wireless MAC Address Filtering** list by following these steps:

1. Click the **Enable** button to enable this function.
2. Select the radio button “Allow the stations specified by any enabled entries in the list to access” for **Filtering Rules**.
3. Delete all or disable all entries if there are any entries already.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4. Click the **Add New...** button.

   1) Enter the MAC address 00-0A-EB-B0-00-0B and 00-0A-EB-00-07-5F in the **MAC Address** field.

   2) Enter wireless station A and B in the **Description** field.

   3) Select **Enabled** in the **Status** drop-down list.

   4) Click the **Save** button.

   5) Click the **Back** button.

The filtering rules that configured should be similar to the following list:


Filtering Rules
Deny the stations specified by any enabled entries in the list to access.
Allow the stations specified by any enabled entries in the list to access.
ID MAC Address Status Description Modify
1 00-0A-EB-B0-00-0B Enabled Wireless station A Modify Delete
2 00-0A-EB-00-07-5F Enabled Wireless station B Modify Delete

4.6.4 Wireless Advanced

Choose menu "**Wireless → Wireless Advanced**", to configure the advanced settings of your wireless network.



Figure 4-24 Wireless Advanced

- **Transmit Power -** Here you can specify the transmit power of Router. You can select High, Middle or Low. High is the default setting and is recommended.
- **Beacon Interval -** Enter a value between 40-1000 milliseconds for Beacon Interval here. The beacons are the packets sent by the Router to synchronize a wireless network. Beacon Interval value determines the time interval of the beacons. The default value is 100.
- **RTS Threshold -** Here you can specify the RTS (Request to Send) Threshold. If the packet is larger than the specified RTS Threshold size, the Router will send RTS frames to a

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

particular receiving station and negotiate the sending of a data frame. The default value is 2346.

- **Fragmentation Threshold -** This value is the maximum size determining whether packets will be fragmented. Setting the Fragmentation Threshold too low may result in poor network performance because of excessive packets. 2346 is the default setting and is recommended.

- **DTIM Interval -** This value determines the interval of the Delivery Traffic Indication Message (DTIM). A DTIM field is a countdown field informing clients of the next window for listening to broadcast and multicast messages. When the Router has buffered broadcast or multicast messages for associated clients, it sends the next DTIM with a DTIM Interval value. You can specify the value between 1-255 Beacon Intervals. The default value is 1, which indicates the DTIM Interval is the same as Beacon Interval.

- **Enable WMM –** The **WMM** function can guarantee the packets with high-priority messages being transmitted preferentially. It is strongly recommended.

- **Enable Short GI -** This function is recommended for it will increase the data capacity by reducing the guard interval time.

- **Enabled AP Isolation -** This function can isolate wireless stations on your network from each other. Wireless devices will be able to communicate with the Router but not with each other. To use this function, check this box. AP Isolation is disabled by default.

☞ **Note: If you are not familiar with the setting of items on this page, it's strongly recommended to keep the provided default values; otherwise it may result in lower wireless network performance.**

4.6.5 Wireless Statistics

Choose menu "**Wireless → Wireless Statistics**", to see the MAC Address, Current Status, Received Packets and Sent Packets for each connected wireless station.



Figure 4-25 Wireless Statistics

- **MAC Address -** The connected wireless station's MAC address

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Current Status -** The connected wireless station's running status, one of **STA-AUTH/ STA-ASSOC/ STA-JOINED/ WPA/ WPA-PSK/ WPA2/ WPA2-PSK/ AP-UP/ AP-DOWN/ Disconnected**
- **Received Packets -** Packets received by the station
- **Sent Packets -** Packets sent by the station

You cannot change any of the values on this page. To update this page and to show the current connected wireless stations, click on the **Refresh** button.

If the numbers of connected wireless stations go beyond one page, click the **Next** button to go to the next page and click the **Previous** button to return the previous page.

☞ **Note: This page will be refreshed automatically every 5 seconds.**

4.7 DHCP



Figure 4-26 The DHCP menu

There are three submenus under the DHCP menu (shown in Figure 4-26), **DHCP Settings**, **DHCP Client List** and **Address Reservation.** Click any of them, and you will be able to configure the corresponding function.

4.7.1 DHCP Settings

Choose menu "**DHCP → DHCP Settings**", to configure the DHCP Server as shown in Figure 4-27. The Router is set up by default as a DHCP (Dynamic Host Configuration Protocol) server, which provides the TCP/IP configuration for all the PC(s) that are connected to the Router on the LAN.


DHCP Settings
DHCP Server: Disable Enable
Start IP Address: 192.168.40.1
End IP Address: 192.168.40.250
Address Lease Time: 120 minutes (1~2880 minutes, the default value is 120)
Default Gateway: 192.168.40.254 (Optional)
Default Domain: (Optional)
Primary DNS: 0.0.0.0 (Optional)
Secondary DNS: 0.0.0.0 (Optional)
Save

Figure 4-27 DHCP Settings

- **DHCP Server - Enable** or **Disable** the DHCP server. If you disable the Server, you must have

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

another DHCP server within your network or else you must configure each computer manually.

- **Start IP Address -** Specify an IP address for the DHCP Server to start with when assigning IP addresses. 192.168.40.1 is the default start address.
- **End IP Address -** Specify an IP address for the DHCP Server to end with when assigning IP addresses. 192.168.40.250 is the default end address.
- **Address Lease Time -** The **Address Lease Time** is the amount of time a network user will be allowed connection to the Router with their current dynamic IP Address. Enter the amount of time in minutes and the user will be "leased" this dynamic IP Address. After the time is up, the user will be automatically assigned a new dynamic IP address. The range of the time is 1 ~ 2880 minutes. The default value is 120 minutes.
- **Default Gateway -** (Optional.) It is suggested to input the IP address of the LAN port of the Router. The default value is 192.168.40.254.
- **Default Domain -** (Optional.) Input the domain name of your network.
- **Primary DNS -** (Optional.) Input the DNS IP address provided by your ISP or consult your ISP.
- **Secondary DNS -** (Optional.) Input the IP address of another DNS server if your ISP provides two DNS servers.

☞ **Note: To use the DHCP server function of the Router, you must configure all computers on the LAN as "Obtain an IP Address automatically".**

4.7.2 DHCP Client List

Choose menu "**DHCP → DHCP Client List**", to view the information about the clients attached to the Router as shown in Figure 4-28.



Figure 4-28 DHCP Clients List

- **Client Name -** The name of the DHCP client
- **MAC Address -** The MAC address of the DHCP client
- **Assigned IP -** The IP address that the Router has allocated to the DHCP client
- **Lease Time -** The time of the DHCP client leased. After the dynamic IP address has expired, a new dynamic IP address will be automatically assigned to the user.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

You cannot change any of the values on this page. To update this page and to show the current attached devices, click the **Refresh** button.

4.7.3 Address Reservation

Choose menu "**DHCP → Address Reservation**", to view and add a reserved address for clients (shown in Figure 4-29).When you specify a reserved IP address for a PC on the LAN, that PC will always receive the same IP address each time when it accesses the DHCP server. Reserved IP addresses should be assigned to the servers that require permanent IP settings.

Figure 4-29 Address Reservation

- **MAC Address -** The MAC address of the PC for which you want to reserve an IP address.
- **Reserved IP Address -** The IP address reserved for the PC by the Router.
- **Status -** The status of this entry, either **Enabled** or **Disabled**.

To Reserve an IP address:

1. Click the **Add New…** button. Then Figure 4-30 will pop up.
2. Enter the MAC address (in XX-XX-XX-XX-XX-XX format.) and IP address (in dotted-decimal notation) of the computer for which you want to reserve an IP address.
3. Click the **Save** button.



Figure 4-30 Add or Modify an Address Reservation Entry

To modify or delete an existing entry:

1. Click the word **Modify** in the entry if you want to modify it, or **Delete** if you want to delete the entry.
2. Modify the information.
3. Click the **Save** button.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Click the **Enable/Disable All** button to make all entries enabled/disabled

Click the **Delete All** button to delete all entries.

Click the **Next** button to go to the next page and Click the **Previous** button to return the previous page.

4.8 Forwarding



Figure 4-31 The Forwarding menu

There are four submenus under the Forwarding menu (shown in Figure 4-31), **Virtual Servers**, **Port Triggering**, **DMZ** and **UPnP**. Click any of them, and you will be able to configure the corresponding function.

4.8.1 Virtual Servers

Choose menu "**Forwarding → Virtual Servers**", to view and add virtual servers as shown in Figure 4-32. Virtual servers can be used for setting up public services on your LAN, such as DNS, Email and FTP. A virtual server is defined as a service port, and all requests from the Internet to this service port will be redirected to the computer specified by the server IP. Any PC that was used for a virtual server must have a static or reserved IP Address because its IP Address may be changed when using the DHCP function.



Figure 4-32 Virtual Servers

- **Service Port -** The numbers of External Ports. You can type a service port or a range of service ports (in XXX – YYY format, XXX is the start port number, YYY is the end port number).
- **Internal Port** - The Internal Service Port number of the PC running the service application. You can leave it blank if the **Internal Port** is the same as the **Service Port**, or enter a specific port number when **Service Port** is a single one.
- **IP Address -** The IP Address of the PC providing the service application.
- **Protocol -** The protocol used for this application, either **TCP**, **UDP**, or **All** (all protocols supported by the Router).
- **Status -** The status of this entry, either **Enabled** or **Disabled**.

To set up a virtual server entry:

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

1. Click the **Add New…** button, the next screen will pop-up as shown in Figure 4-33.
2. Select the service port you want to use from the **Common Service Port** list. If the **Common Service Port** list does not have the service that you want to use, type the service port number or service port range in the **Service Port** box.
3. Type the IP Address of the computer in the **IP Address** box.
4. Select the protocol used for this application, either **TCP**, **UDP**, or **All**.
5. Select **Enabled** in the Status field to enable the virtual server.
6. Click the **Save** button.



Figure 4-33 Add or Modify a Virtual Server Entry

☞ **Note: If your computer or server has more than one type of available service, please select another service, and enter the same IP Address for that computer or server.**

To modify or delete an existing entry:

1. Click the word **Modify** in the entry if you want to modify it, or **Delete** if you want to delete the entry.
2. Modify the information.
3. Click the **Save** button.

Click the **Enable/Disabled All** button to make all entries enabled/disabled.

Click the **Delete All** button to delete all entries.

Click the **Next** button to go to the next page and click the **Previous** button to return the previous page.

☞ **Note: If you set the service port of the virtual server as 80, you must set the Web management port on "Security → Remote Management" page to be any other value except 80 such as 8080. Otherwise there will be a conflict which will disable the virtual server.**

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.8.2 Port Triggering

Choose menu "**Forwarding** → **Port Triggering**", you can view and add port triggering as shown in Figure 4-34. Some applications require multiple connections, like Internet games, video conferencing, Internet calling and so on. These applications cannot work with a pure NAT Router. Port Triggering is used for some of these applications that can work with an NAT Router.



Figure 4-34 Port Triggering

Once the Router is configured, the operation is as follows:

1. A local host makes an outgoing connection using a destination port number defined in the Trigger Port field.
2. The Router records this connection, opens the incoming port or ports associated with this entry in the Port Triggering table, and associates them with the local host.
3. When necessary, the external host will be able to connect to the local host using one of the ports defined in the **Incoming Ports** field.

- **Trigger Port -** The port for outgoing traffic. An outgoing connection using this port will trigger this rule.
- **Trigger Protocol -** The protocol used for Trigger Ports, either **TCP**, **UDP**, or **All** (all protocols supported by the Router).
- **Incoming Ports -** The port or port range used by the remote system when it responds to the outgoing request. A response using one of these ports will be forwarded to the PC that triggered this rule. You can input at most 5 groups of ports (or port sections). Every group of ports must be set apart with ",". For example, 2000-2038, 2050-2051, 2085, 3010-3030.
- **Incoming Protocol -** The protocol used for Incoming Ports Range, either **TCP** or **UDP**, or **ALL** (all protocols supported by the Router).
- **Status -** The status of this entry, either **Enabled** or **Disabled**.

To add a new rule, follow the steps below.

1. Click the **Add New…** button and the screen shown in Figure 4-35 will pop up.
2. Select a common application from the **Common Applications** drop-down list, then the **Trigger Port** field and the **Incoming Ports** field will be automatically filled. If the **Common Applications** do not have the application you need, enter the **Trigger Port** and the **Incoming Ports** manually.
3. Select the protocol used for Trigger Port from the **Trigger Protocol** drop-down list, either **TCP**, **UDP**, or **All**.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4. Select the protocol used for Incoming Ports from the **Incoming Protocol** drop-down list, either **TCP** or **UDP**, or **All.**
5. Select **Enable** in **Status** field.
6. Click the **Save** button to save the new rule.



Figure 4-35 Add or Modify a Port Triggering Entry

To modify or delete an existing entry:

1. Click the word **Modify** in the entry if you want to modify it, or **Delete** if you want to delete the entry.
2. Modify the information.
3. Click the **Save** button.

Click the **Enable All** button to make all entries enabled

Click the **Disable All** button to make all entries disabled.

Click the **Delete All** button to delete all entries

☞ **Note:**

1. **When the trigger connection is released, the corresponding open ports will be closed.**
2. **Each rule is allowed to be used only by one host on LAN synchronously. The trigger connection of other hosts on LAN will be refused.**
3. **Incoming Ports cannot overlap each other.**

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.8.3 DMZ

Choose menu "**Forwarding** → **DMZ**", to view and configure a DMZ host as shown in Figure 4-36. The DMZ host feature allows one local host to be exposed to the Internet for a special-purpose service such as Internet gaming or videoconferencing. DMZ host forwards all the ports at the same time. Any PC whose port is being forwarded must have its DHCP client function disabled and should have a new static IP Address assigned to it because its IP Address may be changed when using the DHCP function.



Figure 4-36 DMZ

To assign a computer or server to be a DMZ server:

1. Check the **Enable** radio button.
2. Enter the IP Address of a local host in the **DMZ Host IP Address** field.
3. Click the **Save** button.

☞ **Note: After you set the DMZ host, the firewall related to the host will not work.**

4.8.4 UPnP

Choose menu "**Forwarding** → **UPnP**", to view the information about **UPnP** (Universal Plug and Play) as shown in Figure 4-37. The UPnP feature allows the devices, such as Internet computers, to access the local host resources or devices as needed. UPnP devices can be automatically discovered by the UPnP service application on the LAN.



Figure 4-37 UPnP

- **Current UPnP Status -** UPnP can be enabled or disabled by clicking the **Enable** or **Disable** button.
- **Current UPnP Settings List -** This table displays the current UPnP information.
  - **App Description -** The description provided by the application in the UPnP request.
  - **External Port -** The external port the Router opens for the application.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Protocol -** The type of protocol the Router opens for the application.
- **Internal Port -** The Internal port the Router opens for local host.
- **IP Address -** The IP address of the UPnP device that is currently accessing the Router.
- **Status -** The status of the port is displayed here. “Enabled” means that the port is still active. Otherwise, the port is inactive.

Click **Refresh** to update the Current UPnP Settings List.

4.9 Security

Figure 4-38 The Security menu

There are four submenus under the Security menu as shown in Figure 4-38: **Basic Security**, **Advanced Security**, **Local Management** and **Remote Management.** Click any of them, and you will be able to configure the corresponding function.

4.9.1 Basic Security

Choose menu “**Security** → **Basic Security**”, to configure basic security as shown in Figure 4-39.



Figure 4-39 Basic Security

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Firewall -** A firewall protects your network from the outside world. Here you can enable or disable the Router's firewall.
  - **SPI Firewall -** SPI (Stateful Packet Inspection, also known as dynamic packet filtering) helps to prevent cyber attacks by tracking the states within a session. It validates that the traffic passing through the session conforms to the protocol. SPI Firewall is enabled by factory default. If you want all the computers on the LAN exposed to the outside world, you can disable it.
- **VPN -** VPN Passthrough must be enabled if you want to allow VPN tunnels using IPSec, PPTP, or L2TP protocols to pass through the Router's firewall.
  - **PPTP Passthrough -** Point-to-Point Tunneling Protocol (PPTP) allows the Point-to-Point Protocol (PPP) to be tunneled through an IP network. To allow PPTP tunnels to pass through the Router, keep the default, **Enabled**.
  - **L2TP Passthrough -** Layer 2 Tunneling Protocol (L2TP) is the method used to enable Point-to-Point sessions via the Internet on the Layer 2 level. To allow L2TP tunnels to pass through the Router, keep the default, **Enabled**.
  - **IPSec Passthrough -** Internet Protocol Security (IPSec) is a suite of protocols for ensuring private, secure communications over Internet Protocol (IP) networks, through the use of cryptographic security services. To allow IPSec tunnels to pass through the Router, keep the default, **Enabled**.
- **ALG -** It is recommended to enable Application Layer Gateway (ALG) because ALG allows customized Network Address Translation (NAT) traversal filters to be plugged into the gateway to support address and port translation for certain application layer "control/data" protocols such as FTP, TFTP, H323 etc.
  - **FTP ALG -** To allow FTP clients and servers to transfer data across NAT, keep the default **Enable**.
  - **TFTP ALG -** To allow TFTP clients and servers to transfer data across NAT, keep the default **Enable**.
  - **H323 ALG -** To allow Microsoft NetMeeting clients to communicate across NAT, keep the default **Enable**.
  - **RTSP ALG** - To allow some media player clients to communicate with some streaming media servers across NAT, click Enable.

Click the **Save** button to save your settings.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.9.2 Advanced Security

Choose menu "**Security → Advanced Security**", to protect the Router from being attacked by TCP-SYN Flood, UDP Flood and ICMP-Flood as shown in Figure 4-40.



Figure 4-40 Advanced Security

- **Packets Statistics Interval (5~60) -** The default value is 10. Select a value between 5 and 60 seconds from the drop-down list. The Packets Statistics Interval value indicates the time section of the packets statistics. The result of the statistics is used for analysis by SYN Flood, UDP Flood and ICMP-Flood.
- **DoS Protection -** Denial of Service protection. Check the Enable or Disable button to enable or disable the DoS protection function. Only when it is enabled, will the flood filters be enabled.

  ☞ **Note: Dos Protection will take effect only when the Traffic Statistics in "System Tool → Traffic Statistics" is enabled.**
- **Enable ICMP-FLOOD Attack Filtering -** Enable or Disable the ICMP-FLOOD Attack Filtering.
- **ICMP-FLOOD Packets Threshold (5~3600) -** The default value is 50. Enter a value between 5 ~ 3600. When the current ICMP-FLOOD Packets number is beyond the set value, the Router will startup the blocking function immediately.
- **Enable UDP-FLOOD Filtering -** Enable or Disable the UDP-FLOOD Filtering.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **UDP-FLOOD Packets Threshold (5~3600) -** The default value is 500. Enter a value between 5 ~ 3600. When the current UPD-FLOOD Packets number is beyond the set value, the Router will startup the blocking function immediately.
- **Enable TCP-SYN-FLOOD Attack Filtering -** Enable or Disable the TCP-SYN-FLOOD Attack Filtering.
- **TCP-SYN-FLOOD Packets Threshold (5~3600) -** The default value is 50. Enter a value between 5 ~ 3600. When the current TCP-SYN-FLOOD Packets numbers is beyond the set value, the Router will startup the blocking function immediately.
- **Ignore Ping Packet From WAN Port to Router -** Enable or Disable Ignore Ping Packet From WAN Port to Router. The default setting is disabled. If enabled, the ping packet from the Internet cannot access the Router.
- **Forbid Ping Packet From LAN Port to Router -** Enable or Disable Forbid Ping Packet From LAN Port to Router. The default setting is disabled. If enabled, the ping packet from LAN cannot access the Router. This function can be used to defend against some viruses.

Click the **Save** button to save the settings.

Click the **Blocked DoS Host List** button to display the DoS host table by blocking.

4.9.3 Local Management

Choose menu "**Security → Local Management**", to configure the management rules as shown in Figure 4-41. The management rules feature allows you to deny computers in LAN from accessing the Router.



Figure 4-41 Local Management

By default, the radio button "**All the PCs on the LAN are allowed to access the Router's Web-Based Utility**" is checked. If you want to allow PCs with specific MAC Addresses to access the Setup page of the Router's Web-Based Utility locally from inside the network, check the radio button "**Only the PCs listed can browse the built-in web pages to perform Administrator tasks**", and then

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

enter each MAC Address in a separate field. The format for the MAC Address is XX-XX-XX-XX-XX-XX (X is any hexadecimal digit). Only the PCs with MAC address listed can use the password to browse the built-in web pages to perform Administrator tasks while all the others will be blocked.

After clicking the **Add** button, your PC's MAC Address will be placed in the list above.

Click the **Save** button to save your settings.

☞ **Note: If your PC is blocked but you want to access the Router again, use a pin to press and hold the Reset Button (hole) on the back panel for about 5 seconds or reset the Router to factory defaults on the Router's Web-Based Utility.**

4.9.4 Remote Management

Choose menu "**Security → Remote Management**", to configure the Remote Management function as shown in Figure 4-42. This feature allows you to manage your Router from a remote location via the Internet.



Figure 4-42 Remote Management

- **Web Management Port -** Web browser access normally uses the standard HTTP service port 80. This Router's default remote management web port number is 80. For greater security, you can change the remote management web port to a custom port by entering that number in the box provided. Choose a number between 1 and 65534 but do not use the number of any common service port.
- **Remote Management IP Address -** This is the current address you will use when accessing your Router from the Internet. This function is disabled when the IP address is set to the default value of 0.0.0.0. To enable this function change 0.0.0.0 to a valid IP address. If set to 255.255.255.255, then all the hosts can access the Router from internet.

☞ **Note:**

1) **To access the Router, you should type your Router's WAN IP address into your browser's address box, followed by a colon and the custom port number. For example, if your Router's WAN address is 202.96.12.8, and the port number used is 8080, enter http://202.96.12.8:8080 in your browser. Later, you may be asked for the Router's password. After successfully entering the username and password, you will be able to access the Router's web-based utility.**

2) **Be sure to change the Router's default password to a very secure password.**

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.10 Parental Control

Choose menu "**Parental Control**", to configure the parental control as shown in Figure 4-43. The Parental Control function can be used to control the internet activities of the child, limit the child to access certain websites and restrict the time of surfing.



Figure 4-43 Parental Control Settings

- **Parental Control -** Check **Enable** if you want this function to take effect, otherwise check **Disable**.
- **MAC Address of Parental PC -** In this field, enter the MAC address of the controlling PC, or you can make use of the **Copy To Above** button below.
- **MAC Address of Your PC -** This field displays the MAC address of the PC that is managing this Router. If the MAC Address of your adapter is registered, you can click the Copy To Above button to fill this address to the MAC Address of Parental PC field above.
- **Website Description -** Description of the allowed website for the PC controlled.
- **Schedule -** The time period allowed for the PC controlled to access the Internet. For detailed information, please go to "**Access Control** → **Schedule**".
- **Modify -** Here you can edit or delete an existing entry.

To add a new entry, please follow the steps below.

1. Click the **Add New…** button and the screen shown in Figure 4-44 will pop up.
2. Enter the MAC address of the PC (e.g. 00-11-22-33-44-AA) you'd like to control in the MAC Address of Child PC field. Or you can choose the MAC address from the All Address in Current LAN drop-down list.
3. Give a description (e.g. Allow Google) for the website allowed to be accessed in the Website Description field.
4. Enter the allowed domain name of the website, either the full name or the keywords (e.g. google) in the Allowed Domain Name field. Any domain name with keywords in it (www.google.com, www.google.com.hk) will be allowed.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

5. Select from the Effective Time drop-down list the schedule (e.g. Schedule_1) you want the entry to take effect. If there are not suitable schedules for you, click the **Schedule** in red below to go to the Advance Schedule Settings page and create the schedule you need.
6. In the Status field, you can select **Enabled** or **Disabled** to enable or disable your entry.
7. Click the **Save** button.

Click the **Enable All** button to enable all the rules in the list.

Click the **Disable All** button to disable all the rules in the list.

Click the **Delete All** button to delete all the entries in the table.

Click the **Next** button to go to the next page, or click the **Previous** button return to the previous page.


Add or Modify Parental Control Entry
The Schedule is based on the time of the Router. The time can be set in "System Tools -> Time settings".
MAC Address of Children's PC:
All MAC Address In Current LAN:
--Please Select--
Website Description:
Allowed Website Name:
Effective Time:
Anytime
The time schedule can be set in "Access Control -> Schedule"
Status:
Enabled
Save
Back

Figure 4-44 Add or Modify Parental Control Entry

For example: If you desire that the children's PC with MAC address 00-11-22-33-44-AA can access www.google.com on Saturday only while the parent PC with MAC address 00-11-22-33-44-BB is without any restriction, you should follow the settings below.

1. Click "**Parental Control**" menu on the left to enter the Parental Control Settings page. Check Enable and enter the MAC address 00-11-22-33-44-BB in the MAC Address of Parental PC field.
2. Click "**Access Control → Schedule**" on the left to enter the Schedule Settings page. Click **Add New...** button to create a new schedule with Schedule Description is Schedule_1, Day is Sat and Time is all day-24 hours.
3. Click "**Parental Control**" menu on the left to go back to the Add or Modify Parental Control Entry page:

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- Click **Add New...** button.
- Enter 00-11-22-33-44-AA in the **MAC Address of Children's PC** field.
- Enter "Allow Google" in the **Website Description** field.
- Enter "www.google.com" in the **Allowed Website Name** field.
- Select "Schedule_1" you create just now from the **Effective Time** drop-down list.
- In **Status** field, select Enable.

4. Click **Save** to complete the settings.

Then you will go back to the Parental Control Settings page and see the following list, as shown in Figure 4-45.



Figure 4-45 Parental Control Settings

4.11 Access Control

Figure 4-46 Access Control

There are four submenus under the Access Control menu as shown in Figure 4-46: **Rule**, **Host**, **Target** and **Schedule**. Click any of them, and you will be able to configure the corresponding function.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.11.1 Rule

Choose menu "**Access Control** → **Rule**", to view and set Access Control rules as shown in Figure 4-47.



Figure 4-47 Access Control Rule Management

- **Enable Internet Access Control -** Select the check box to enable the Internet Access Control function, so the Default Filter Policy can take effect.
- **Rule Name -** The unique name of the rule is displayed.
- **Host -** The host selected in the corresponding rule.
- **Target -** The target selected in the corresponding rule.
- **Schedule -** The schedule selected in the corresponding rule.
- **Action -** The action the Router takes to deal with the packets. It could be **Allow** or **Deny**. **Allow** means that the Router permits the packets to go through the Router. **Deny** means that the Router rejects the packets to go through the Router.
- **Status -** This field displays the status of the rule. **Enabled** means the rule will take effect, **Disabled** means the rule will not take effect.
- **Modify -** Here you can edit or delete an existing rule.

There are two methods to add a new rule.

Method One:

1. Click **Setup Wizard** button and the screen shown in Figure 4-48 will appear.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure 4-48 Quick Setup – Create a Host Entry

- **Mode** - There are two options, **IP Address** and **MAC Address**. You can select either of them from the drop-down list.
- **Host Description** - In this field, create a unique description for the host (e.g. Host_1).

If the **IP Address** is selected, you can see the following item:

- **LAN IP Address** - Enter the IP address or address range of the host in dotted-decimal format (e.g. 192.168.40.23).

If the MAC Address is selected, you can see the following item:

- **MAC Address** - Enter the MAC address of the host in XX-XX-XX-XX-XX-XX format (e.g. 00-11-22-33-44-AA).

2. Click **Next** when finished creating the host entry, and the screen shown in Figure 4-49 will appear.



Figure 4-49 Quick Setup – Create an Access Target Entry

- **Mode** - There are two options, IP Address and Domain Name. You can choose either of them from the drop-down list.
- **Target Description** - In this field, create a description for the target. Note that this description should be unique (e.g. Target_1).

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

If the **IP Address** is selected, you will see the following items:

- **IP Address** - Enter the IP address (or address range) of the target (targets) in dotted-decimal format (e.g. 192.168.40.23).
- **Target Port** - Specify the port or port range for the target. For some common service ports, you can make use of the Common Service Port item below.
- **Protocol** - There are four options, All, TCP, UDP, and ICMP. Select one of them from the drop-down list for the target.
- **Common Service Port** - A list of some common service ports. Select one from the drop-down list, and the corresponding port number will be filled in the Target Port field automatically. For example, if you select "FTP", "21" will be filled in the Target Port automatically.

If the **Domain Name** is selected, you will see the following items:

- **Domain Name** - Here you can enter 4 domain names, either the full name or the keywords (for example, google). Any domain name with keywords in it (www.google.com, www.google.cn) will be blocked or allowed.

3. Click **Next** when finished creating the access target entry, and the next screen will appear as shown in Figure 4-50.



Figure 4-50 Quick Setup – Create an Advanced Schedule Entry

- **Schedule Description** - In this field, create a description for the schedule. Note that this description should be unique (e.g. Schedule_1).
- **Day** - Choose Select Days and select the certain day (days), or choose Everyday.
- **Time** - Select "24 hours", or specify the Start Time and Stop Time yourself.
- **Start Time** - Enter the start time in HHMM format (HHMM are 4 numbers). For example 0800 is 8:00.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Stop Time** - Enter the stop time in HHMM format (HHMM are 4 numbers). For example 2000 is 20:00.

4. Click **Next** when finishing creating the advanced schedule entry, and the screen shown in Figure 4-51 will appear.



Figure 4-51 Quick Setup – Create an Internet Access Control Entry

- **Rule** - In this field, create a name for the rule. Note that this name should be unique (e.g. Rule_1).
- **Host** - In this field, select a host from the drop-down list for the rule. The default value is the **Host Description** you previously set.
- **Target** - In this filed, select a target from the drop-down list for the rule. The default value is the **Target Description** you previously set.
- **Schedule** - In this field, select a schedule from the drop-down list for the rule. The default value is the **Schedule Description** you previously set.
- **Status** - In this field, there are two options, **Enabled** or **Disabled**. Select **Enabled** so that the rule will take effect. Select **Disabled** so that the rule won't take effect.

5. Click **Finish** to complete adding a new rule.

Method Two:

1. Click the **Add New…** button and the next screen will pop up as shown in Figure 4-52.
2. Give a name (e.g. Rule_1) for the rule in the **Rule Name** field.
3. Select a host from the **Host** drop-down list or choose "**Click Here To Add New Host List**".
4. Select a target from the **Target** drop-sown list or choose "**Click Here To Add New Target List**".
5. Select a schedule from the **Schedule** drop-down list or choose "**Click Here To Add New Schedule**".
6. In the **Status** field, select **Enabled** or **Disabled** to enable or disable your entry.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

7. Click the **Save** button.



Figure 4-52 Add Internet Access Control Entry

For example: If you desire to allow the host with MAC address 00-11-22-33-44-AA to access www.google.com only from 18:00 to 20:00 on Saturday and Sunday, and forbid other hosts in the LAN to access the Internet, you should follow the settings below:

1. Click the submenu **Rule of Access Control** in the left to return to the Rule List page. Select Enable Internet Access Control and choose "Allow the packets specified by any enabled access control policy to pass through the Router".
2. We recommend that you click **Setup Wizard** button to finish all the following settings.
3. Click the submenu **Host of Access Control** in the left to enter the Host List page. Add a new entry with the Host Description is Host_1 and MAC Address is 00-11-22-33-44-AA.
4. Click the submenu **Target of Access Control** in the left to enter the Target List page. Add a new entry with the Target Description is Target_1 and Domain Name is www.google.com.
5. Click the submenu **Schedule of Access Control** in the left to enter the Schedule List page. Add a new entry with the Schedule Description is Schedule_1, Day is Sat and Sun, Start Time is 1800 and Stop Time is 2000.
6. Click the submenu **Rule of Access Control** in the left, Click **Add New...** button to add a new rule as follows:
   - In Rule Name field, create a name for the rule. Note that this name should be unique, for example Rule_1.
   - In Host field, select Host_1.
   - In Target field, select Target_1.
   - In Schedule field, select Schedule_1.
   - In Status field, select Enable.
   - Click Save to complete the settings.

Then you will go back to the Access Control Rule Management page and see the following list.

ID	Rule Name	Host	Target	Schedule	Enable	Modify
1	Rule_1	Host_1	Target_1	Schedule_1	☑	Edit Delete

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.11.2 Host

Choose menu "**Access Control** → **Host**", to view and set a Host list as shown in Figure 4-53. The host list is necessary for the Access Control Rule.



Figure 4-53 Host Settings

- **Host Description –** A unique description of the host.
- **Information -** The information about the host. It can be IP or MAC.
- **Modify -** To modify or delete an existing entry.

To add a new entry, please follow the steps below.

1. Click the **Add New…** button.
2. In the **Mode** field, select IP Address or MAC Address.
   - If you select IP Address, the screen shown is Figure 4-54.
     1) In **Host Description** field, create a unique description for the host (e.g. Host_1).
     2) In **LAN IP Address** field, enter the IP address.
   - If you select MAC Address, the screen shown is Figure 4-55.
     1) In **Host Description** field, create a unique description for the host (e.g. Host_1).
     2) In **MAC Address** field, enter the MAC address.
3. Click the **Save** button to complete the settings.

Click the **Delete All** button to delete all the entries in the table.

Click the **Next** button to go to the next page, or click the **Previous** button return to the previous page.



Figure 4-54 Add or Modify a Host Entry

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure 4-55 Add or Modify a Host Entry

For example: If you desire to restrict the internet activities of host with MAC address 00-11-22-33-44-AA, you should first follow the settings below:

1. Click **Add New...** button in Figure 4-53 to enter the Add or Modify a Host Entry page.
2. In **Mode** field, select MAC Address from the drop-down list.
3. In **Host Description** field, create a **unique** description for the host (e.g. Host_1).
4. In **MAC Address** field, enter 00-11-22-33-44-AA.
5. Click **Save** to complete the settings.

Then you will go back to the Host Settings page and see the following list.



4.11.3 Target

Choose menu "**Access Control** → **Target**", to view and set a Target list as shown in Figure 4-56. The target list is necessary for the Access Control Rule.



Figure 4-56 Target Settings

- **Target Description -** The unique description of the target.
- **Information -** The target can be an IP address, port, or domain name.
- **Modify -** To modify or delete an existing entry.

To add a new entry, please follow the steps below.

1. Click the **Add New…** button.
2. In **Mode** field, select IP Address or Domain Name.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- If you select **IP Address**, the screen shown is as in Figure 4-57.

  1) In the **Target Description** field, create a unique description (e.g. Target_1).

  2) In the **IP Address** field, enter the IP address of the target.

  3) Select a common service from **Common Service Port** drop-down list, so that the **Target Port** will be automatically filled. If the **Common Service Port** drop-down list doesn't have the service you want, specify the **Target Port** manually.

  4) In **Protocol** field, select TCP, UDP, ICMP or ALL.



Figure 4-57 Add or Modify an Access Target Entry

- If you select **Domain Name**, the screen shown in Figure 4-58.

  1) In **Target Description** field, create a unique description for the target (e.g. Target_1).

  2) In **Domain Name** field, enter the domain name, either the full name or the keywords (for example google) in the blank. Any domain name with keywords in it (www.google.com, www.google.hk) will be blocked or allowed. You can enter 4 domain names.

3. Click the **Save** button.

Click the **Delete All** button to delete all the entries in the table.

Click the **Next** button to go to the next page, or click the **Previous** button return to the previous page.



Figure 4-58 Add or Modify an Access Target Entry

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

For example: If you desire to restrict the internet activities of host with MAC address 00-11-22-33-44-AA in the LAN to access **www.google.com** only, you should first follow the settings below:

1. Click **Add New…** button in Figure 4-56 to enter the Add or Modify an Access Target Entry page.
2. In **Mode** field, select Domain Name from the drop-down list.
3. In **Target Description** field, create a unique description for the target (e.g. Target_1).
4. In **Domain Name** field, enter www.google.com.
5. Click **Save** to complete the settings.

Then you will go back to the Target Settings page and see the following list,

ID	Target Description	Information	Modify
1	Target_1	www.google.com	Edit Delete

4.11.4 Schedule

Choose menu "**Access Control** → **Schedule**", to view and set a Schedule list as shown in Figure 4-59. The Schedule list is necessary for the Access Control Rule.



Figure 4-59 Schedule Settings

- **Schedule Description -** The unique description of the schedule.
- **Day -** The day(s) in a week.
- **Time -** The time period in a day.
- **Modify -** Edit or delete an existing schedule.

To add a new schedule, follow the steps below.

1. Click **Add New...** button shown in Figure 4-59 and the screen shown in Figure 4-60 will pop up.
2. In the **Schedule Description** field, create a unique description for the schedule (e.g. Schedule_1).
3. In the **Day** field, select the day or days you need.
4. In the **Time** field, you can select all day-24 hours or you may enter the Start Time and Stop Time in the corresponding field.
5. Click **Save** to complete the settings.

Click the **Delete All** button to delete all the entries in the table.

Click the **Next** button to go to the next page, or click the **Previous** button return to the previous page.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure 4-60 Advanced Schedule Settings

For example: If you desire to restrict the internet activities of host with MAC address 00-11-22-33-44-AA to access www.google.com only from **18:00 to 20:00** on **Saturday** and **Sunday**, you should first follow the settings below:

1. Click **Add New...** button shown in Figure 4-59 to enter the Advanced Schedule Settings page.
2. In **Schedule Description** field, create a unique description for the schedule (e.g. Schedule_1).
3. In **Day** field, check the Select Days radio button and then select Sat and Sun.
4. In **Time** field, enter 1800 in Start Time field and 2000 in Stop Time field.
5. Click **Save** to complete the settings.

Then you will go back to the Schedule Settings page and see the following list.

ID	Schedule Description	Day	Time	Modify
1	Schedule_1	Sat Sun	18:00 - 20:00	Edit Delete

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.12 Advanced Routing



Figure 4-61 Advanced Routing Menu

There are two submenus under the Advanced Routing menu (shown in Figure 4-61): **Static Routing List** and **System Routing Table**. Click any of them, and you will be able to configure the corresponding function.

4.12.1 Static Routing

Choose menu **"Advanced Routing → Static Routing"**, to configure a static route as shown in Figure 4-62. A static route is a pre-determined path that network information must travel to reach a specific host or network.



Figure 4-62 Static Routing

To add static routing entries, follow the steps below.

1. Click **Add New…** shown in Figure 4-62, you will see the screen shown in Figure 4-63.



Figure 4-63 Add or Modify a Static Route Entry

2. Enter the following data.

- **Destination Network -** The **Destination Network** is the address of the network or host that you want to assign to a static route.
- **Subnet Mask -** The **Subnet Mask** determines which portion of an IP Address is the network portion, and which portion is the host portion.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Default Gateway -** This is the IP Address of the default gateway device that allows for the contact between the Router and the network or host.

3. Select **Enabled** or **Disabled** for this entry on the **Status** drop-down list.

4. Click the **Save** button to make the entry take effect.

Click the **Delete** button to delete the entry.

Click the **Enable All** button to enable all the entries.

Click the **Disable All** button to disable all the entries.

Click the **Delete All** button to delete all the entries.

Click the **Previous** button to view the information in the previous screen, click the **Next** button to view the information in the next screen.

4.12.2 System Routing Table

Choose menu **"Advanced Routing → System Routing Table**", to view all of the valid route entries in use. The Destination IP address, Subnet Mask, Gateway, and Interface will be displayed for each entry.



- **Destination Network -** The Destination Network is the address of the network or host to which the static route is assigned.
- **Subnet Mask -** The Subnet Mask determines which portion of an IP address is the network portion, and which portion is the host portion.
- **Gateway -** This is the IP address of the gateway device that allows for contact between the Router and the network or host.
- **Interface -** This interface tells you whether the Destination IP Address is on the **LAN & WLAN** (internal wired and wireless networks), the **WAN(Internet)**.

Click the **Refresh** button to refresh the data displayed.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.13 Bandwidth Control



Figure 4-64

There are two submenus under the Bandwidth Control menu as shown in Figure 4-64. Click any of them, and you will be able to configure the corresponding function. The detailed explanations for each submenu are provided below.

4.13.1 Control Settings

Choose menu "**Bandwidth Control** → **Control Settings**", to configure the Egress Bandwidth and Ingress Bandwidth as shown in Figure 4-65. Their values you configure should be less than 100000Kbps. For optimal control of the bandwidth, please select the right Line Type and ask your ISP for the total bandwidth of the egress and ingress.



Figure 4-65 Bandwidth Control Settings

- **Enable Bandwidth Control -** Check this box so that the Bandwidth Control settings can take effect.
- **Line Type -** Select the right type for you network connection. If you don't know how to choose, please ask your ISP for the information.
- **Egress Bandwidth** - The upload speed through the WAN port.
- **Ingress Bandwidth -** The download speed through the WAN port.

4.13.2 Rules List

Choose menu "**Bandwidth Control** → **Rules List**", to view and configure the Bandwidth Control rules as shown in Figure 4-66.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure 4-66 Bandwidth Control Rules List

- **Description -** This is the information about the rules such as address range.
- **Egress bandwidth -** This field displays the max and mix upload bandwidth through the WAN port, the default is 0.
- **Ingress bandwidth -** This field displays the max and mix download bandwidth through the WAN port, the default is 0.
- **Enable -** This displays the status of the rule.
- **Modify -** Click **Modify** to edit the rule. Click **Delete** to delete the rule.

To add/modify a Bandwidth Control rule, follow the steps below.

Step 1: Click **Add New…**shown in Figure 4-66, and you will see a screen as shown in Figure 4-67.

Step 2: Enter the information like the screen shown below.



Figure 4-67 Bandwidth Control Rule Settings

Step 3: Click the **Save** button.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.14 IP & MAC Binding



Figure 4-68 the IP & MAC Binding menu

There are two submenus under the IP &MAC Binding menu (shown in Figure 4-68): **Binding Settings** and **ARP List**. Click any of them, and you will be able to scan or configure the corresponding function. The detailed explanations for each submenu are provided below.

4.14.1 Binding Settings

This page displays the **IP & MAC Binding Setting** table; as shown in Figure 4-69.



Figure 4-69 Binding Settings

- **MAC Address -** The MAC address of the controlled computer in the LAN.
- **IP Address -** The assigned IP address of the controlled computer in the LAN.
- **Bind -** Check this option to enable ARP binding for a specific device.
- **Modify -** To modify or delete an existing entry.

When you want to add or modify an IP & MAC Binding entry, you can click the **Add New…** button or **Modify** button, and then you will go to the screen shown in Figure 4-70.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure 4-70 IP & MAC Binding Settings

To add IP & MAC Binding entries, follow the steps below.

1. Click the **Add New...** button as shown in Figure 4-69.
2. Enter the MAC Address and IP Address.
3. Select the Bind checkbox.
4. Click the **Save** button to save it.

To modify or delete an existing entry, follow the steps below.

1. Find the desired entry in the table.
2. Click **Modify** or **Delete** as desired on the **Modify** column.

To find an existing entry, follow the steps below.

1. Click the **Find** button as shown in Figure 4-69.
2. Enter the MAC Address or IP Address.
3. Click the **Find** button in the page as shown in Figure 4-71.



Figure 4-71 Find IP & MAC Binding Entry

Click the **Enable All** button to make all entries enabled.

Click the **Delete All** button to delete all entries.

4.14.2 ARP List

To manage the computer, you could observe the computers in the LAN by checking the relationship of MAC address and IP address on the ARP list, and you could configure the items on the ARP list also.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

This page displays the ARP List; it shows all the existing IP & MAC Binding entries as shown in Figure 4-72.



Figure 4-72 ARP List

- **MAC Address -** The MAC address of the controlled computer in the LAN.
- **IP Address -** The assigned IP address of the controlled computer in the LAN.
- **Status -** Indicates whether or not the MAC and IP addresses are bound.
- **Configure -** Load or delete an item.
  - **Load -** Load the item to the IP & MAC Binding list.
  - **Delete -** Delete the item.

Click the **Bind All** button to bind all the current items, available after enable.

Click the **Load All** button to load all items to the IP & MAC Binding list.

Click the **Refresh** button to refresh all items.

☞ **Note: An item could not be loaded to the IP & MAC Binding list if the IP address of the item has been loaded before. Error warning will prompt as well. Likewise, "Load All" only loads the items without interference to the IP & MAC Binding list.**

4.15 Dynamic DNS

Choose menu "**Dynamic DNS**", to configure the Dynamic DNS function.

The Router offers a **DDNS** (Dynamic Domain Name System) feature, which allows the hosting of a website, FTP server, or e-mail server with a fixed domain name (named by yourself) and a dynamic IP address, and then your friends can connect to your server by entering your domain name no matter what your IP address is. Before using this feature, you need to sign up for DDNS service providers such as www.comexe.cn, www.dyndns.org, or www.no-ip.com. The Dynamic DNS client service provider will give you a password or key.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.15.1 Comexe.cn DDNS

If the dynamic DNS **Service Provider** you select is www.comexe.cn, the page will appear as shown in Figure 4-73.



Figure 4-73 Comexe.cn DDNS Settings

To set up for DDNS, follow these instructions:

1. Type the **Domain Name** received from your dynamic DNS service provider.
2. Type the **User Name** for your DDNS account.
3. Type the **Password** for your DDNS account.
4. Click the **Login** button to log in to the DDNS service.

Connection Status -The status of the DDNS service connection is displayed here.

Click **Logout** to log out of the DDNS service.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.15.2 Dyndns.org DDNS

If the dynamic DNS **Service Provider** you select is www.dyndns.org, the page will appear as shown in Figure 4-74.



Figure 4-74 Dyndns.org DDNS Settings

To set up for DDNS, follow these instructions:

1. Type the **User Name** for your DDNS account.
2. Type the **Password** for your DDNS account.
3. Type the **Domain Name** you received from dynamic DNS service provider here.
4. Click the **Login** button to log in to the DDNS service.

Connection Status -The status of the DDNS service connection is displayed here.

Click **Logout** to logout of the DDNS service.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.15.3 No-ip.com DDNS

If the dynamic DNS **Service Provider** you select is www.no-ip.com, the page will appear as shown in Figure 4-75.



Figure 4-75 No-ip.com DDNS Settings

To set up for DDNS, follow these instructions:

1. Type the **User Name** for your DDNS account.
2. Type the **Password** for your DDNS account.
3. Type the **Domain Name** you received from dynamic DNS service provider.
4. Click the **Login** button to log in the DDNS service.

Connection Status - The status of the DDNS service connection is displayed here.

Click **Logout** to log out the DDNS service.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.16 System Tools



Figure 4-76 The System Tools menu

Choose menu "**System Tools**", and you can see the submenus under the main menu: **Time Settings**, **Diagnostic**, **Firmware Upgrade**, **Factory Defaults, Backup & Restore, Reboot, Password, System Log** and **Statistics.** Click any of them, and you will be able to configure the corresponding function. The detailed explanations for each submenu are provided below.

4.16.1 Time Settings

Choose menu "**System Tools** → **Time Settings**", to configure the time as shown in Figure 4-77.



Figure 4-77 Time settings

- **Time zone -** Select your local time zone from this drop-down list.
- **Date -** Enter your local date in MM/DD/YY into the right blanks.
- **Time -** Enter your local time in HH/MM/SS into the right blanks.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **NTP Server 1 / NTP Server 2 -** Enter the address or domain of the **NTP Server 1** or **NTP Server 2**, and then the Router will get the time from the NTP Server preferentially. In addition, the Router built-in some common NTP Servers, so it can get time automatically once it connects the Internet.
- **Enable Daylight Saving -** Check the box to enable the Daylight Saving function.
- **Start -** The time to start the Daylight Saving. Select the month in the first field, the week in the second field, the day in the third field and the time in the last field.
- **End -** The time to end the Daylight Saving. Select the month in the first field, the week in the second field, the day in the third field and the time in the last field.
- **Daylight Saving Status -** Displays the status whether the Daylight Saving is in use.

To set time manually:

1. Select your local time zone.
2. Enter the **Date** in Month/Day/Year format.
3. Enter the **Time** in Hour/Minute/Second format.
4. Click **Save**.

To set time automatically:

1. Select your local time zone.
2. Enter the address or domain of the **NTP Server I** or **NTP Server II**.
3. Click the **Get GMT** button to get system time from Internet if you have connected to the Internet.

To set Daylight Saving:

1. Check the box to enable Daylight Saving.
2. Select the start time from the drop-down lists in the **Start** field.
3. Select the end time from the drop-down lists in the **End** field.
4. Click the **Save** button to save the settings.



Note:

1. **This setting will be used for some time-based functions such as firewall. You must specify your time zone once you login to the router successfully, otherwise, these functions will not take effect.**
2. **The time will be lost if the router is turned off.**
3. **The Router will automatically obtain GMT from the Internet if it is configured accordingly.**
4. **The Daylight Saving will take effect one minute after the configurations are completed.**

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.16.2 Diagnostic

Choose menu "**System Tools** → **Diagnostic**", to perform Ping or Traceroute function to check connectivity of your network as shown in Figure 4-78.



Figure 4-78 Diagnostic Tools

- **Diagnostic Tool -** Check the radio button to select one diagnostic too.
  - **Ping -** This diagnostic tool troubleshoots connectivity, reachability, and name resolution to a given host or gateway.
  - **Traceroute -** This diagnostic tool tests the performance of a connection.

☞ **Note: You can use ping / traceroute to test both numeric IP address or domain name. If pinging / tracerouting the IP address is successful, but pinging / tracerouting the domain name is not, you might have a name resolution problem. In this case, ensure that the domain name you are specifying can be resolved by using Domain Name System (DNS) queries.**

- **IP Address/Domain Name -** Type the destination IP address (such as 192.168.40.1) or Domain name (such as Legrand).
- **Pings Count -** The number of Ping packets for a Ping connection.
- **Ping Packet Size -** The size of Ping packet.
- **Ping Timeout -** Set the waiting time for the reply of each Ping packet. If there is no reply in the specified time, the connection is overtime.
- **Traceroute Max TTL -** The max number of hops for a Traceroute connection.

Click **Start** to check the connectivity of the Internet.

The **Diagnostic Results** page displays the result of diagnosis.

If the result is similar to the screen shown in Figure 4-79, the connectivity of the Internet is fine.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com


Diagnostic Results
Pinging 192.168.40.254 with 64 bytes of data:
Reply from 192.168.40.254: bytes=64 time=1 TTL=64 seq=1
Reply from 192.168.40.254: bytes=64 time=1 TTL=64 seq=2
Reply from 192.168.40.254: bytes=64 time=1 TTL=64 seq=3
Reply from 192.168.40.254: bytes=64 time=1 TTL=64 seq=4
Ping statistics for 192.168.40.254:
Packets: Sent = 4, Received = 4, Lost = 0 (0% loss)
Approximate round trip times in milliseconds:
Minimum = 1, Maximum = 1, Average = 1

Figure 4-79 Diagnostic Results

☞ **Note: Only one user can use this tool at one time. Options "Number of Pings", "Ping Size" and "Ping Timeout" are used for Ping function. Option "Tracert Hops" is used for Traceroute function.**

4.16.3 Firmware Upgrade

Choose menu "**System Tools** → **Firmware Upgrade**", to update the latest version of firmware for the Router as shown in Figure 4-80.



Figure 4-80 Firmware Upgrade

- **Firmware Version -** This displays the current firmware version.
- **Hardware Version -** This displays the current hardware version. The hardware version of the upgrade file must accord with the Router's current hardware version.

To upgrade the Router's firmware, follow these instructions below:

1. Download a more recent firmware upgrade file from our website.
2. Type the path and file name of the update file into the **File** field. Or click the **Browse** button to locate the update file.
3. Click the **Upgrade** button.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

☞ **Note:**

1) **New firmware versions are posted on the Legrand website and can be downloaded for free. There is no need to upgrade the firmware unless the new firmware has a new feature you want to use. However, when experiencing problems caused by the Router rather than the configuration, you can try to upgrade the firmware.**
2) **When you upgrade the Router's firmware, you may lose its current configurations, so before upgrading the firmware please write down some of your customized settings to avoid losing important settings.**
3) **Do not turn off the Router or press the Reset button while the firmware is being upgraded, otherwise, the Router may be damaged.**
4) **The Router will reboot after the upgrading has been finished.**

4.16.4 Factory Defaults

Choose menu "**System Tools** → **Factory Defaults**", to restore the configurations of the Router to factory defaults as shown in Figure 4-81.



Figure 4-81 Restore Factory Default

Click the **Restore** button to reset all configuration settings to their default values.

- The default **User Name**: admin
- The default **Password**: admin
- The default **IP Address**: 192.168.40.254
- The default **Subnet Mask**: 255.255.255.0

☞ **Note:**

1. **Any settings you have saved will be lost when the default settings are restored.**
2. **When you press and hold the WPS/Reset button for more than 5 seconds, you will reset the router.**

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.16.5 Backup & Restore

Choose menu "**System Tools** → **Backup & Restore**", to save the current configuration of the Router as a backup file and restore the configuration via a backup file as shown in Figure 4-82.



Figure 4-82 Backup & Restore Configuration

- Click the **Backup** button to save all configuration settings as a backup file in your local computer.
- To upgrade the Router's configuration, follow these instructions.
  - Click the **Browse…** button to locate the update file for the Router, or enter the exact path of the file into the text box.
  - Click the **Restore** button.

☞ **Note: The current configuration will be overwritten by the Restored configuration file. The Restore process lasts for 20 seconds and the Router will restart automatically. Keep the Router on during the upgrading process to prevent any damage.**

4.16.6 Reboot

Choose menu "**System Tools** → **Reboot**", and click the **Reboot** button to reboot the Router as shown in Figure 4-83.

Figure 4-83 Reboot the Router

Some settings of the Router will take effect only after rebooting, which include

- Changing the LAN IP Address (system will reboot automatically).
- Changing the DHCP Settings.
- Changing the Wireless configurations.
- Changing the Web Management Port.
- Upgrading the firmware of the Router (system will reboot automatically).
- Restoring the Router's settings to factory defaults (system will reboot automatically).
- Restoring the configuration file (system will reboot automatically.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4.16.7 Password

Choose menu “**System Tools** → **Password**”, to change the factory default user name and password of the Router as shown in Figure 4-84.



Figure 4-84 Password

It is strongly recommended that you change the factory default user name and password of the Router, because all users who try to access the Router's Web-based utility or Quick Setup will be prompted for the Router's user name and password, and most routers default to admin / admin.

☞ **Note: The new user name or password must not exceed 14 characters in length and not include any spaces. Enter the new Password twice to confirm.**

Click the **Save** button when finished.

Click the **Clear All** button to clear all.

4.16.8 System Log

Choose menu “**System Tools** → **System Log**”, to view the logs of the Router.


System Log
Auto Mail Feature: Disabled
Mail Settings
Log Type: ALL
Log Level: ALL
Index Time Type Level Log Content
1 1st day 00:19:34 OTHER INFO User clear system log.
Time = 2012-01-01 0:19:34 1176s
H-Ver = PW-RN501D v4 00000000 : S-Ver = 3.13.17 Build 120525 Rel.55437n
L = 192.168.40.254 : M = 255.255.255.0
W1 = DHCP : W = 0.0.0.0 : M = 0.0.0.0 : G = 0.0.0.0
Refresh
Save Log
Mail Log
Clear Log
Previous
Next
Current No. 1
Page

Figure 4-85 System Log

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **Auto Mail Feature -** Indicates whether auto mail feature is enabled or not.
- **Mail Settings -** Set the receiving and sending mailbox address, server address, validation information as well as the timetable for Auto Mail Feature, as shown in Figure 4-86.



Figure 4-86 Mail Account Settings

- **From -** Your mail box address. The Router would connect it to send logs.
- **To -** Recipient's address. The destination mailbox where the logs would be received.
- **SMTP Server -** Your SMTP server. It corresponds with the mailbox filled in the From field.
- **Authentication -** Most SMTP Servers require Authentication. It is required by most mailboxes that need User Name and Password to log in.

☞ **Note: Only when you select Authentication, do you have to enter the User Name and Password in the following fields.**

- **User Name -** Your mail account name filled in the From field. The part behind @ is excluded.
- **Password -** Your mail account password.
- **Confirm The Password -** Enter the password again to confirm.
- **Enable Auto Mail Feature -** Select it to mail logs automatically. You can mail the current logs either at a specified time everyday or by intervals. Enter the desired time or interval (only one of these options may be selected) in the corresponding field as shown in Figure 4-86

Click **Save** to keep your settings.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Click **Back** to return to the previous page.

- **Log Type -** By selecting the log type, only logs of this type will be shown.
- **Log Level -** By selecting the log level, only logs of this level will be shown.
- **Refresh -** Refresh the page to show the latest log list.
- **Save Log -** Click to save all the logs in a txt file.
- **Mail Log -** Click to send an email of current logs manually according to the address and validation information set in Mail Settings.
- **Clear Log -** All the logs will be deleted from the Router permanently, not just from the page.

Click the **Next** button to go to the next page, or click the **Previous** button return to the previous page.

4.16.9 Statistics

Choose menu "**System Tools** → **Statistics**", to view the statistics of the Router, including total traffic and the value of the last Packets Statistic Interval in seconds.



Figure 4-87 Statistics

- **Current Statistics Status -** Enable or Disable. The default value is disabled. To enable, click the **Enable** button. If disabled, the function of DoS protection in Security settings will disabled.
- **Packets Statistics Interval （5-60） -** The default value is 10. Select a value between 5 and 60 seconds in the drop-down list. The Packets Statistic interval indicates the time section of the packets statistic.
- **Sorted Rules –** Choose how displayed statistics are sorted.

Select the **Auto-refresh** checkbox to refresh automatically.

Click the **Refresh** button to refresh immediately.

Click **Reset All** to reset the values of all the entries to zero.

Click **Delete All** to delete all entries in the table.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Statistics Table:

IP/MAC Address		The IP and MAC address are displayed with related statistics.
Total	**Packets**	The total number of packets received and transmitted by the Router.
	Bytes	The total number of bytes received and transmitted by the Router.
Current	**Packets**	The total number of packets received and transmitted in the last Packets Statistic interval seconds.
	Bytes	The total number of bytes received and transmitted in the last Packets Statistic interval seconds.
	ICMP Tx	The number of the ICMP packets transmitted to WAN per second at the specified Packets Statistics interval. It is shown like “current transmitting rate / Max transmitting rate”.
	UDP Tx	The number of UDP packets transmitted to the WAN per second at the specified Packets Statistics interval. It is shown like “current transmitting rate / Max transmitting rate”.
	TCP SYN Tx	The number of TCP SYN packets transmitted to the WAN per second at the specified Packets Statistics interval. It is shown like “current transmitting rate / Max transmitting rate”.
Modify	**Reset**	Reset the value of he entry to zero.
	Delete	Delete the existing entry in the table.

There would be 5 entries on each page. Click **Previous** to return to the previous page and **Next** to the next page.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Appendix A: FAQ

1. How do I configure the Router to access Internet by ADSL users?

1) First, configure the ADSL Modem in RFC1483 bridge mode.

2) Connect the Ethernet cable from your ADSL Modem to the WAN port on the Router. The telephone cord plugs into the Line port of the ADSL Modem.

3) Log in to the Router, click the "**Network**" menu on the left of your browser, and click "**WAN**" submenu. On the **WAN** page, select "PPPoE" for WAN Connection Type. Type user name in the "User Name" field and password in the "Password" field, finish by clicking **Connect**.



Figure A-1 PPPoE Connection Type

4) If your ADSL lease is in "pay-according-time" mode, select "Connect on Demand" or "Connect Manually" for Internet connection mode. Type an appropriate number for "Max Idle Time" to avoid wasting paid time. Otherwise, you can select "Connect Automatically" for Internet connection mode.

☞ **Note:**

1) **Sometimes the connection cannot be disconnected although you specify a time in the Max Idle Time box, since some applications run continually in the background on the Internet.**

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

2. How do I configure the Router to access Internet by Ethernet users?

1) Log in to the Router, click the “**Network**” menu on the left of your browser, and click "**WAN**" submenu. On the **WAN** page, select “Dynamic IP” for "WAN Connection Type", finish by clicking **Save**.

2) Some ISPs require that you register the MAC Address of your adapter, which is connected to your cable/DSL Modem during installation. If your ISP requires MAC register, log in to the Router and click the "**Network**" menu link on the left of your browser, and then click "**MAC Clone**" submenu link. On the "**MAC Clone**" page, if your PC’s MAC address is proper MAC address, click the **Clone MAC Address** button and your PC’s MAC address will fill in the "WAN MAC Address" field. Or else, type the MAC Address into the "WAN MAC Address" field. The format for the MAC Address is XX-XX-XX-XX-XX-XX. Then click the **Save** button. It will take effect after rebooting.



Figure A-3 MAC Clone

3. I want to use NetMeeting, what do I need to do?

1) If you start NetMeeting as a sponsor, you don’t need to do anything with the Router.

2) If you start as a response, you need to configure Virtual Server or DMZ Host and make sure the H323 ALG is enabled.

3) To configure a Virtual Server: Log in to the Router, click the “**Forwarding**” menu on the left of your browser, and click "**Virtual Servers**" submenu. On the "**Virtual Servers**" page, click **Add New…**. Then on the “**Add or Modify a Virtual Server Entry**” page, enter “11130” in the “Service Port” box, and your IP address in the “IP Address” box, and remember to **Enable** and **Save**.



Figure A-4 Virtual Servers

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure A-5 Add or Modify a Virtual server Entry

4) To enable DMZ Host: Log in to the Router, click the "**Forwarding**" menu on the left of your browser, and click "**DMZ**" submenu. On the "DMZ" page, click **Enable** radio button and type your IP address into the "DMZ Host IP Address" field, using 192.168.40.200 as an example, remember to click the **Save** button.



Figure A-6 DMZ

5) To enable H323 ALG: Log in to the Router, click the "**Security**" menu on the left of your browser, and click "**Basic Security**" submenu. On the "**Basic Security**" page, check the **Enable** radio button next to **H323 ALG**. Remember to click the **Save** button.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com



Figure A-7 Basic Security

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343

©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

4. I want to build a WEB Server on the LAN, what should I do?

1) Because the WEB Server port 80 will interfere with the WEB management port 80 on the Router, you must change the WEB management port number to avoid interference.

2) To change the WEB management port number: Log in to the Router, click the "**Security**" menu on the left of your browser, and click "**Remote Management**" submenu. On the "**Remote Management**" page, type a port number except 80, such as 88, into the "Web Management Port" field. Click **Save** and reboot the Router.



Figure A-8 Remote Management

☞ **Note: If the above configuration works, remotely access the Router by typing 192.168.40.254:88 (the Router's LAN IP address: Web Management Port) in the address field of the Web browser.**

3) Log in  click the "**Virtua** …en on the "**Add c** …**ce Port**", and yc … example, remem

Figure A-9 Virtual Servers



Figure A-10 Add or Modify a Virtual server Entry

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

5. The wireless stations cannot connect to the Router.

1) Make sure the "**Enable Wireless Router Radio**" is checked under Wireless Settings.

2) Make sure that the wireless stations' SSID agree with the Router's SSID.

3) Make sure the wireless stations have the right KEY for encryption when the Router is encrypted.

4) If the wireless connection is ready, but you can't access the Router, check the IP Address of your wireless stations to insure they are in the same IP subnet.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343

©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Appendix B: Configuring the PC

In this appendix, we'll go over how to configure the TCP/IP correctly in Windows XP. First make sure your Ethernet Adapter is working, refer to the adapter's manual if necessary.

1. Configure TCP/IP component

1) On the Windows taskbar, click the **Start** button, and then click **Control Panel**.

2) Click the **Network and Internet Connections** icon, and then click on the **Network Connections** tab in the appearing window.

3) Right click the icon shown below, and click on Properties on the prompt page.



Figure B-1

4) In the prompt page shown below, double click on the **Internet Protocol (TCP/IP)**.



Figure B-2

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343

©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

5) The following **TCP/IP Properties** window will display as shown below.

You have two ways to configure the **TCP/IP** protocol below, automatically or manually:

- **Setting IP address automatically**

Select **Obtain an IP address automatically**, and select **Obtain DNS server address automatically**, as shown in Figure B-3:


Internet Protocol (TCP/IP) Properties
General
Alternate Configuration
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address:
Subnet mask:
Default gateway:
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server:
Alternate DNS server:
Advanced...
OK
Cancel

Figure B-3

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Setting IP address manually

1 Select **Use the following IP address** radio button.

2 If the Router's LAN IP address is 192.168.40.254, specify the **IP address** as 192.168.40.x (x is from 1 to 250), and the **Subnet mask** as 255.255.255.0.

3 Type the Router's LAN IP address (the default IP is 192.168.40.254) into the **Default gateway** field.

4 Select **Use the following DNS server addresses**. In the **Preferred DNS Server** field you can enter the same value as the **Default gateway** or type the local DNS server IP address.


Internet Protocol (TCP/IP) Properties
General
You can get IP settings assigned automatically if your network supports this capability. Otherwise, you need to ask your network administrator for the appropriate IP settings.
Obtain an IP address automatically
Use the following IP address:
IP address: 192 . 168 . 40 . 101
Subnet mask: 255 . 255 . 255 . 0
Default gateway: 192 . 168 . 40 . 254
Obtain DNS server address automatically
Use the following DNS server addresses:
Preferred DNS server: 202 . 96 . 134 . 133
Alternate DNS server:
Advanced...
OK
Cancel

Now click **OK** to keep your settings.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Appendix C: Specifications

General	
Standards	IEEE 802.3, IEEE 802.3u, IEEE 802.11b, IEEE 802.11g and IEEE 802.11n
Protocols	TCP/IP, PPPoE, DHCP, ICMP, NAT, SNTP
Ports	One 10/100M Auto-Negotiation WAN RJ45 port, Four 10/100M Auto-Negotiation LAN RJ45 ports supporting Auto MDI/MDIX
Cabling Type	10BASE-T: UTP category 3, 4, 5 cable (maximum 100m) EIA/TIA-568 100Ω STP (maximum 100m)
	100BASE-TX: UTP category 5, 5e cable (maximum 100m) EIA/TIA-568 100Ω STP (maximum 100m)
LEDs	Power, System, WLAN, WAN, LAN (1-4), WPS
Safety & Emissions	FCC, CE
Wireless	
Frequency Band	2.4~2.4835GHz
Radio Data Rate	11n：up to 300Mbps（Automatic） 11g：54/48/36/24/18/12/9/6Mbps（Automatic） 11b：11/5.5/2/1Mbps（Automatic）
Frequency Expansion	DSSS(Direct Sequence Spread Spectrum)
Modulation	DBPSK, DQPSK, CCK, OFDM, 16-QAM, 64-QAM
Security	WEP/WPA/WPA2/WPA2-PSK/WPA-PSK
Sensitivity @PER	270M: -68dBm@10% PER; 130M: -68dBm@10% PER 108M: -68dBm@10% PER; 54M: -68dBm@10% PER 11M: -85dBm@8% PER; 6M: -88dBm@10% PER 1M: -90dBm@8% PER
Environmental and Physical	
Temperature	Operating : 0°C~40℃ (32℉~104℉)
	Storage: -40°C~70℃(-40℉~158℉)
Humidity	Operating: 10% - 90% RH, Non-condensing
	Storage: 5% - 90% RH, Non-condensing

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

Appendix D: Glossary

- **802.11n -** 802.11n builds upon previous 802.11 standards by adding MIMO (multiple-input multiple-output). MIMO uses multiple transmitter and receiver antennas to allow for increased data throughput via spatial multiplexing and increased range by exploiting the spatial diversity, perhaps through coding schemes like Alamouti coding. The Enhanced Wireless Consortium (EWC) [3] was formed to help accelerate the IEEE 802.11n development process and promote a technology specification for interoperability of next-generation wireless local area networking (WLAN) products.
- **802.11b -** The 802.11b standard specifies a wireless networking at 11 Mbps using direct-sequence spread-spectrum (DSSS) technology and operating in the unlicensed radio spectrum at 2.4GHz, and WEP encryption for security. 802.11b networks are also referred to as Wi-Fi networks.
- **802.11g -** specification for wireless networking at 54 Mbps using direct-sequence spread-spectrum (DSSS) technology, using OFDM modulation and operating in the unlicensed radio spectrum at 2.4GHz, and backward compatibility with IEEE 802.11b devices, and WEP encryption for security.
- **DDNS** (**D**ynamic **D**omain **N**ame **S**ystem) **-** The capability of assigning a fixed host and domain name to a dynamic Internet IP Address.
- **DHCP** (**D**ynamic **H**ost **C**onfiguration **P**rotocol) **-** A protocol that automatically configure the TCP/IP parameters for the all the PC(s) that are connected to a DHCP server.
- **DMZ** (**De**militarized **Z**one) **-** A Demilitarized Zone allows one local host to be exposed to the Internet for a special-purpose service such as Internet gaming or videoconferencing.
- **DNS** (**D**omain **N**ame **S**ystem) **–** An Internet Service that translates the names of websites into IP addresses.
- **Domain Name -** A descriptive name for an address or group of addresses on the Internet.
- **DSL** (**D**igital **S**ubscriber **L**ine) **-** A technology that allows data to be sent or received over existing traditional phone lines.
- **ISP** (**I**nternet **S**ervice **P**rovider) **-** A company that provides access to the Internet.
- **MTU** (**Maximum Transmission Unit**) **-** The size in bytes of the largest packet that can be transmitted.
- **NAT** (**N**etwork **A**ddress **T**ranslation) **-** NAT technology translates IP addresses of a local area network to a different IP address for the Internet.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com

- **PPPoE** (**P**oint to **P**oint **P**rotocol **o**ver **E**thernet) **-** PPPoE is a protocol for connecting remote hosts to the Internet over an always-on connection by simulating a dial-up connection.
- **SSID -** A **S**ervice **S**et **Id**entification is a thirty-two character (maximum) alphanumeric key identifying a wireless local area network. For the wireless devices in a network to communicate with each other, all devices must be configured with the same SSID. This is typically the configuration parameter for a wireless PC card. It corresponds to the ESSID in the wireless Access Point and to the wireless network name.
- **WEP** (**W**ired **E**quivalent **P**rivacy) **-** A data privacy mechanism based on a 64-bit or 128-bit or 152-bit shared key algorithm, as described in the IEEE 802.11 standard.
- **Wi-Fi -** A trade name for the 802.11b wireless networking standard, given by the Wireless Ethernet Compatibility Alliance (WECA, see http://www.wi-fi.net), an industry standards group promoting interoperability among 802.11b devices.
- **WLAN** (**W**ireless **L**ocal **A**rea **N**etwork) **-** A group of computers and associated devices communicate with each other wirelessly, which network serving users are limited in a local area.

301 Fulling Mill Road, Suite G
Middletown, PA 17057
(800)-321-2343
©Copyright 2012 by Legrand, Inc All Rights Reserved.
www.onqlegrand.com